




OIL PUMP (for 4WD and Pre-Runner)

COMPONENTS




N*m (kgf*cm, ft*lbf) : Specified torque





PRE RUNNER:**4WD:**

PROPELLER WITH CENTER BEARING SHAFT ASSEMBLY




N*m (kgf*cm, ft*lb) : Specified torque











N*m (kgf*cm, ft*lb) : Specified torque

● Non-reusable part







N*m (kgf*cm, ft*lbf) : Specified torque




COOLER COMPRESSOR ASSEMBLY



N*m (kgf*cm, ft*lbf) : Specified torque








[N*m (kgf*cm, ft.*lbf)] : Specified torque

● Non-reusable part

← Apply MP grease



N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

Y