



TIRE PRESSURE WARNING RECEIVER

COMPONENTS

for Double Cab:




for Double Cab:




N*m (kgf*cm, ft*lb) : Specified torque


for Double Cab:




w/ Woofer:




for Regular Cab on Separate Seat Type:




for Regular Cab on Bench Seat Type:



for Access Cab:




for Double Cab:



N*m (kgf*cm, ft*lb) : Specified torque

for Regular Cab:




$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

H


B087473E04

for Access Cab:



$\boxed{\text{N*m (kgf*cm, ft*lb)}} : \text{Specified torque}$

for Double Cab:




N*m (kgf*cm, ft*lbf) : Specified torque


H

B087409E03

for Regular Cab:




for Bench Seat Type:



N*m (kgf*cm, ft*lb) : Specified torque

for Access Cab:





N*m (kgf*cm, ft*lb) : Specified torque


H

B087434E03


for Double Cab:

**w/ EC Mirror:**


for Regular Cab:




for Access Cab:



w/ EC Mirror:





N*m (kgf*cm, ft*lbf) : Specified torque