

HOW TO PROCEED WITH TROUBLESHOOTING

1

VEHICLE BROUGHT TO WORKSHOP

NEXT

2

CUSTOMER PROBLEM ANALYSIS (See page [IN-26](#))

NEXT

3

PASSENGER AIRBAG ON/OFF INDICATOR CHECK (See page [RS-362](#))

NEXT

4

DTCs CHECK (Present and Past DTCs) (See page [RS-365](#))

(a) Check for DTCs.

Result

Result	Proceed to
DTC is output.	A
DTC is not output.	B

B

GO TO PROBLEM SYMPTOMS TABLE

A

5

DTCs CHART (See page [RS-368](#))

NEXT

RS

6

CIRCUIT INSPECTION

NEXT

7

REPAIR OR REPLACEMENT

NEXT

8

DTC CLEARANCE (Present and Past DTCs) (See page [RS-365](#))

(a) Clear the DTCs.

NEXT

9 DTC CHECK (Present and Past DTCs) (See page [RS-365](#))

(a) Check for DTCs.

Result

Result	Proceed to
DTC is not output.	A
DTC is output.	B

B

Go to step 5

A

10 SYMPTOM SIMULATION (See page [RS-361](#))

(a) Check the passenger airbag ON/OFF indicator condition.

Result

Result	Proceed to
Passenger airbag ON/OFF indicator is operating normally.	A
Passenger airbag ON/OFF indicator (OFF) and SRS warning light come on.	B

B

Go to step 5

A

11 CONFIRMATION TEST

NEXT

END