

FRONT DOOR (w/ Power Window)

COMPONENTS

ACCESS CAB:



POWER WINDOW REGULATOR
MASTER SWITCH ASSEMBLY


PASSENGER SIDE:



POWER WINDOW REGULATOR
SWITCH ASSEMBLY

DOUBLE CAB:


POWER WINDOW REGULATOR MASTER SWITCH ASSEMBLY



SCREW — x2

FRONT DOOR TRIM PANEL ASSEMBLY LH


OUTER REAR VIEW MIRROR ASSEMBLY LH



FRONT DOOR LOWER FRAME BRACKET GARNISH LH

CLIP

N*m (kgf*cm, ft.*lbf) ; Specified torque



$\boxed{N*m \text{ (kgf*cm, ft.*lbf)}}$: Specified torque

● Non-reusable part

