


Chery A113 2007 – 2015 fuse box diagram

The instrument panel fuse panel



Chery A113 – fuse box diagram – instrument panel


No.	A	Function/component
F1	10	Combined instruments

F2	10	Rear view mirror, brake switch, BCM
F3	10	ABS control
F4	10	Air Bag
F5	–	Not used
F6	15	Washer, rear wiper power supply, sunroof control
F7	10	Steering power supply, A/C relay coil
F8	15	Front wiper
F9	15	Cigarette lighter
F10	10	Radio/player control

F11	–	Not used
F12	25	Start
F13	10	Diagnosis Access
F14	10	Braking Lamp
F15	20	Audio device
F16	15	Horn, fog lamp
F17	–	Not used
F18	10	Clearance lamp, ceiling lamp
F19	15	Alarm switch

F20	10	Lamp switch, instrument
F21	20	Sunroof power supply
F22	20	Rear defroster
Relay		
R1	Blower Relay	
R2	Steering relay	
R3	Front wiper relay	

Engine compartment fuse box



Chery A113 – fuse box diagram – engine compartment

No.	A	Function/component
SF1	30	Fan. high speed
SF2	30	BCM
SF3	30	A/C
SF4	40	Instrument electric
SF5	30	ABS

SF6	30	ABS
EF1	20	Fan. low speed
EF2	15	Front fog lamp
EF3	10	ECU
EF4	15	Fuel pump
EF5	30	Primary relay
EF6	10	Compressor
EF7	15	Oxygen sensor
EF8	–	Not used

EF9	15	Ignition coil
EF10	10	Backup lamp
EF11	10	Right position lamp
EF12	10	Left position lamp
EF13	10	Right high beam
EF14	10	Left high beam
EF15	10	Right low beam
EF16	10	Left low beam
EF17	10	Spare

EF18	10	Spare
EF19	10	Spare
EF20	10	Spare
Relay		
R1	Front Fog Lamp Relay	
R2	Fan High Speed Relay	
R3	Fan Low Speed Relay	
R4	Low Beam Relay	
R5	Compressor	

R6	High Beam Relay
R7	Main relay
R8	Electric Fuel Pump