


Chrysler Pacifica 2004 – 2008 fuse box diagram

Fuse box diagram



Chrysler Pacifica – fuse box diagram

No.	A	Protected Component
1	40	ABS
2	–	–
3	30	Fuse: “46”, “47”, “48”, “49”, “50”
4	40	Body Control Module
5	40	Rear Window Defogger Relay
6	30	Front Wiper (On/Off) Relay (Front Wiper (High/Low) Relay)
7	40	Starter Relay

8	40	Circuit Breaker – Power Seat
9	40	Power Sunroof Module
10	30	Trailer Tow Connector
11	40	Power Liftgate Module
12	–	–
13	40	Radiator Fan Relay
14	–	–
15	40	ABS
24	20	Rear Power Outlet
25	15	Radio, Audio Amplifier, Navigation Module, Hands Free Module, Overhead Console, Automatic Day/Night Mirror, Power Sunroof Module
26	20	Cigar Lighter/Power Outlet – Front Console
27	–	–
28	25	Horn Relay
29	20	Stop Lamp Switch, Instrument Cluster

30	10	Ignition Switch (Skreem Module, Park Assist Module, Body Control Module, Instrument Panel Switch POD, Starter Relay, Powertrain Control Module, Air Conditioner Compressor Clutch Relay, Fuel Pump Relay)
31	20	Body Control Module
34	10	Rear Booster Fan Control Module
35	–	–
36	20	Transmission Control Relay (Transmission Solenoid/Pressure Switch, Powertrain Control Module)
37	25	Auto Shut Down Relay (Powertrain Control Module, Injector, Ignition Coil, Short Runner Valve Solenoid (3.5L), Noise Suppressor)
38	20	Manifold Tuning Valve Relay (3.5L), Air Conditioner Compressor Clutch Relay
39	20	Fuel Pump Relay, Powertrain Control Module
40	40	Driver Door Module (Power Window, Power Mirror, Power Seat)
41	40	Passenger Door Module (Power Window, Power Mirror)
42	40	Front Blower Power Module (ATC), Blower Motor Resistor Block (MTC)
44	25	Seat Heater Interface Modue, Heated Seat Switch – Left/Right Middle Row
45	10	ABS, A/C Heater Control (MTC), Auto Temp Control (ATC)
46	20	Passenger Door Module (Power Window, Door Lock, Power Mirror, Courtesy Lamp)

47	20	Driver Door Module (Power Window, Door Lock, Power Mirror, Power Seat, Courtesy Lamp)
48	15	Body Control Module, Navigation Module, Overhead Console, Hands Free Module
49	25	Audio Amplifier
50	15	Radio, Skream Module, Instrument Panel Switch POD, Auto Temp Control, DVD/CD Changer, Satellite Radio
PTC		
1	13	Power Outlet – Instrument Panel, Data Link Connector
Relay		
R1	Rear Window Defogger	
R2	Transmission Control	
R3	Run	
R4	–	
R5	Fuel Pump	
R6	Door Node	
R7	Starter	
R8	–	

R9	Front Blower Motor
R10	Rear Booster Fan
R11	Horn
R12	Auto Shut Down
R13	Air Conditioner Compressor Clutch
R14	–
R15	3.5L: Manifold Tuning Valve
R16	Front Wiper (On/Off)
R17	Front Wiper (High/Low)
R18	Accessory