



2013 Audi TT | TTS | TT RS Coupe

Quick Reference Guide

Vorsprung durch Technik **Audi** 

Diagram illustrating the steering wheel and dashboard controls of the Audi A8, numbered 1 through 15:

1. Headlight switch
2. Steering wheel adjustment lever
3. Steering wheel adjustment lever
4. Steering wheel adjustment lever
5. Gear selector
6. Gear selector
7. Gear selector
8. Gear selector
9. Gear selector
10. Gear selector
11. Gear selector
12. Gear selector
13. Gear selector
14. Gear selector
15. Gear selector

1 Release buttons for:

- ## 2 Power windows

Be careful when closing the windows. Check to see that no one is in the way, or serious personal injury could result.

Adjust the knob:

- The mirror glass moves in the direction that the knob is pressed.

- 4 Hood release
- 5 Data Link Connector for On Board Diagnostics (OBD II)
- 6 Door handle and central locking switch
 locked
 unlocked
- 7 Light switch
- 8 Instrument lighting
- 9 Cruise control
- 10 Multifunction steering wheel controls
- 11 Turn signal and high beam lever
- 12 Instruments and indicator lights



- 13 Windshield wiper controls and trip computer buttons
- 14 Steering wheel position adjuster

⚠ WARNING

The column should only be adjusted when the vehicle is at a complete standstill.

- 15 Ignition lock
- 16 Navigation system or radio system
- 17 Passenger airbag indicator light
- 18 Climate control system
- 19 Passenger's seat heating
- 20 Driver's seat heating
- 21 Selector lever or shift lever
- 22 Ashtray with cigarette lighter
- 23  Audi magnetic ride or  Sport mode  Electronic Stabilization Control (ESC)  Emergency flashers  Rear spoiler
- 24 Parking brake

Pairing Cell Phone to Bluetooth™ System

The cell phone must be paired one time with the cell phone preparation in the vehicle. The steps required for this procedure depend on the cell phone you are using.

- Vehicle must be stationary with ignition on. Bluetooth system will be visible for approximately 5 minutes.
- On the cell phone, select the menu that searches for Bluetooth capable devices.
- On the cell phone, select „Audi UHV“ and confirm.
- Enter the PIN „1234“ on the cell phone. The time allowed for entering the PIN is limited to approximately 30 seconds.
- Confirm the connection in your cell phone too when requested.
- A Bluetooth symbol appears in the status line of the navigation system if the pairing was successful.

Various phones require that a confirmation be accepted for automatic future connections between the phone and the navigation system as well as acknowledging the synchronization of the address book between the phone and the navigation system.

Telephone voice operation

You can operate many telephone functions comfortably using voice operation.

Requirement: Switch the ignition and navigation system on, do not have any phone calls in progress.

Switching the system on: Press the  button on the multifunction steering wheel briefly. Say your command (refer to the examples) after the <Beep>.

Switching the system off: Press and hold the  button or say <Cancel>.

Sample commands

Help commands: Say <Help>. Possible commands are shown in the display and are read by the system.

Dialing a phone number: Say <Dial number>. Say the desired number in individual numbers or in groups of numbers. Say <Dial>.

Storing a name tag: Select the desired directory entry. Say <Store name>. Say the name under which the directory entry should be stored.

Selecting a directory entry: Say <Select name>. Say the name tag. Say <Dial>.

Deleting a name tag: Say <Delete name>. Say the name tag. Say <Yes>.

Adjusting the seats

- 1 **Adjusting the lumbar support:**
Press on the respective area of the switch.
- 2 **Adjusting seat height and forward/back position:**
 -  Front of the seat cushion up/down
 -  Back of the seat cushion up/down
 -  Seat up/down
 -  Seat forward/back
- 3 **Adjusting the backrest:**
 -  Backrest forward/back
- 4 **Entry assistance:**
Pull the lever up and fold the backrest forward.



Adjusting the headrests

Hold the sides of the headrest with both hands and slide it. Adjust the head restraint so the upper edge is as even as possible with the top of your head.



WARNING

Thoroughly review your Owner's Manual for warnings and other important information about proper restraint use and what you can do to reduce the risk of injury in accidents. Failure to properly use restraint systems can cause serious personal injury.

WARNING

Never install rear facing child seats or infant carriers on the passenger seat. A child will be seriously injured or killed when the passenger airbag inflates.

WARNING

Always fasten safety belts before driving off. Always make sure passengers are properly restrained. Children 12 years old and younger must ride in the rear seat and be properly restrained as indicated in the Owner's Manual. The airbag is supplemental and does not replace safety belt use.

WARNING

Front seat passengers must never ride in a moving vehicle with the seatback reclined. The risk of personal injury increases with increasing rearward angle of the seatback. Safety belts only offer protection when the seatback is upright and belts are properly positioned on the body. Adjust your seats only when the vehicle is at a complete standstill.

WARNING

The airbag system cannot protect you properly if you are seated too close to any of the airbag locations. When adjusting their seat positions, it is important that both the driver and front passenger keep their upper bodies at a minimum safe distance of 10 inches (25 cm) between the chest and the steering wheel/instrument panel.

Climate control

Left rotary switch: Temperature selection

Center rotary switch: Switch the climate control switch on/off and regulate the fan speed.

Right rotary switch: Air distribution

-  **Automatic mode**
Set the desired temperature and press the button.
-  **Recirculation mode**
Circulate and filter the air inside the passenger compartment
-  **Switch the air conditioning system on/off**
-  **Defrost the windshield/side windows**
-  **Rear window defroster**




Sport mode or Audi magnetic ride

Two suspension systems in one vehicle

Standard driving mode: Suspension setting that emphasizes comfort.

Sport driving mode: Sporty suspension setting.
Press the  or  button to activate/deactivate.



S tronic

Selector lever positions

- P** Park
- R** Reverse
- N** Neutral (Idle)
- D** Drive
- S** Sport

Releasing the selector lever lock and engaging a gear:

Switch the ignition on, press the brake pedal and press the lock button on the selector lever. Place the selector lever in the D or S position to drive forward.

tiptronic: To shift manually, move the selector lever to the right out of the D position. The driver information system displays the gears.

Shifting up/down: Press the selector lever forward/back.

Rear spoiler

Increasing driving stability

The downward force at the rear axle is increased when the rear spoiler is extended.

Automatic mode:

The rear spoiler extends at speeds above approximately 75 mph (120 km/h) and retracts at speeds under 50 mph (80 km/h).

Manual mode:


Press the  button briefly to extend the rear spoiler.

Press the  button again at speeds between 10 mph (20 km/h) and 75 mph (120 km/h) to retract the rear spoiler.

Press and hold the  button at speeds below 10 mph (20 km/h) to retract the rear spoiler.

WARNING

Never drive at speeds higher than 85 mph (140 km/h) if the spoiler is not deployed.



Cruise control

The **CRUISE**/ indicator light appears in the instrument cluster when the system is switched on.

Switching on/off: Pull/press the lever **2**.

Storing the speed: Press the button **1**.

Changing the stored speed:

Press the lever up (faster) or down (slower).




WARNING

Improper use of the cruise control can cause collisions, other accidents and serious personal injury. Always read and heed the Warnings in the Owner's Manual.

Starting the engine

Switching the ignition on/starting the engine

Insert the key into the ignition lock.



Switching the ignition on: Turn the key to the **2** position.

Starting the engine: Place the selector lever in the P or N position, press the brake and turn the key to the **3** position until the engine starts.


Stopping the engine: Turn the key to the **1** position.

Hill Descent Assist

In vehicles with automatic transmission, Hill Descent Assist helps when driving down declines.

Activating: Move the selector lever to the D or S position and press the brake pedal. The current speed is maintained as long as physical and technical limits permit.

Deactivating: Press the accelerator pedal.



Fuel cap

Tighten fuel cap clockwise as far as it will go. The Malfunction Indicator Light will illuminate, if your fuel cap is not properly sealed.


The label on the inside of the fuel filler door indicates the correct fuel type.



Fuel filler door

Opening: Pull the  button in the driver's door.

Closing: Press the fuel filler door in until it latches.



Engine oil

For the applicable oil specifications, refer to the Owner's Manual.

Tire pressure monitoring system

The TPMS must be reset via MMI (Navigation system/Sound system) if the tire pressure is adjusted or wheels are changed.



Tire pressures

The label with the correct tire pressures is located on the driver's door pillar.

Navigation system

Components

1 Driver information system

2 Multifunction steering wheel

Roll the **left thumbwheel** to select a menu item in the driver information system. Press the thumbwheel to confirm the menu item.

Press the **MODE button** to switch between the active radio source, navigation system and telephone.

Press the **voice recognition button** briefly to activate the voice recognition system. After the <Beep>, you can say the desired commands.

To deactivate, press and hold the **voice recognition button** until you hear the message <Cancel>.

Roll the **right thumbwheel** to adjust the volume.

Press the right thumbwheel to repeat the last navigation announcement.





3 Display

4 Function buttons

Call up main functions such as **FM/AM**.

5 On/Off button

Switching on/off:

Press briefly/press and hold.

Adjusting the volume:

Turn. **Mute:** Press briefly

6 Control buttons

Activate the functions currently shown in the corners of the MMI display.

7 Control knob

To select a menu item: Turn the knob.

To confirm your selection: Press the knob.


⚠ WARNING

Distraction causes accidents:

- Never enter data while driving!
- Obey traffic laws & road signs!
- Refer to the Owner's Manual!

Operation

Operation is the same in all functions.



A Selecting: Turn the knob.

B Confirming: Press the knob.

C Calling up menus in the display corners: Press the appropriate button.

Storing a radio station



- 1 Press the **FM/AM** function button.
- 2 Turn the control knob and select the desired station.



- 3 Press and hold the control knob.



- 4 Press the control knob to store in the next free memory preset or
- 5 Turn the control knob to store in a specific location. Then press the control knob to set.



- 1 Press the **NAV** function button.



- 2 Turn the control knob and select "City/Zip".
- 3 Press the control knob to confirm.



- 4 Turn the control knob to select the first letter of the destination.
- 5 Press the control knob to confirm.



- 6 Enter the remaining letters of the destination using the same procedure until the desired location name is displayed.



- 7 When you have entered the destination, turn the control knob and select "OK".
- 8 Press the control knob to confirm.



- 9 Select the menu item "Start route guidance".
- 10 Press the control knob to confirm. The route is calculated.

Placing a Phone call



Dialing a phone number from a call list:

- Press the **TEL** function button.
- Press the **Memory** control button.
- Turn the control knob to select “Dialed numbers”, “Missed calls” or “Received calls” and press to confirm. The phone numbers from the selected list appear in the display.
- Turn the control knob to select the desired number and press to confirm.
- Press the “Dial” control button.



Accessing directory contacts:

- Press the **NAME** function button
- Turn the control knob to select “Show list” and press to confirm.
- Turn the control knob to select the desired contact and press to confirm.
- Turn the control knob to select the desired number and press to confirm.

Setting the clock








Select in the navigation system: **SETUP** function button > **Settings** control button > **Time/Date format**

Time format: Turn the control knob to **24h** or **am/pm**.

Date format: Turn the control knob to **DD.MM** or **MM/DD**.

If the instrument cluster source is not available, the time and date are received through GPS. If this is the case, GPS appears under the **Time source** menu item. The GPS time can be set under the **GMT +/-** menu item.

For additional information on indicator lights, refer to your vehicle Owner's Manual.

 Brake malfunction (USA)	 Electromechanical steering	 Tire pressure too low (check immediately)	 Battery voltage too high or too low	 Audi magnetic ride
 Brake malfunction (CAN)	 Clutch overheating	 TPMS Tire pressure monitoring system malfunction	 Low fuel level	 Rear spoiler
 Safety systems (USA)	 Clutch pedal	 EPC Electronic power control	 Windshield washer fluid level low	 ¹ MPH ₂ Speed warning (USA)
 Safety systems (CAN)	 Electronic Stabilization Control (ESC)	 CHECK Malfunction Indicator Lamp (USA)	 Defective light bulb	 ¹ Km/h ₂ Speed warning (CAN)
 Safety belt	 OFF Electronic Stabilization Control (ESC)	 Malfunction Indicator Lamp (CAN)	 BRAKE LIGHT Defective brake light (USA)	 Electromechanical steering
 Generator	 ABS Anti-lock brake system (USA)	 ! Engine speed limitation	 Defective brake light (CAN)	 Turn signals/ Emergency flasher
 Engine oil pressure too low	 (ABS) Anti-lock brake system (CAN)	 MIN Check engine oil level	 Dynamic headlight range control defective	 CRUISE Cruise control activated (USA)
 Cooling system malfunction	 Worn brake pads	 SENSOR Engine oil sensor malfunction	 Adaptive Light defective	 Cruise control activated (CAN)
			 Light/rain sensor defective	 High beam

© 2012 AUDI AG

Audi is constantly improving their products. Modifications in form, equipment, and technology are possible. No legal commitment is implied by the information, illustrations, and descriptions in this Quick Reference Guide. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Reprinting, reproduction or translation, in whole or in part, is not permitted without written permission from Audi of America, Inc. Subject to modification without notice. Concept and design: Pfriemer GmbH.

Audi TT | TTS | TT RS Coupe
Kurzanleitung
Nordamerika
Englisch 05.2012
131.562.8JC.21



1315628JC21

www.audi.com