

64 11 ...**Installing servodrive***Installation:*

If necessary, align shaft of flap(s) to be actuated to position of servodrive to be installed.