

52 13 390**Removing and installing or replacing
front left or right head restraint**

Press latch mechanism (1) and lift out head restraint (2).

