


35 21 041

Replacing spring for brake pedal

**Necessary preliminary tasks:**

- Remove [trim panel for pedal mechanism](#).



Disconnect return spring (1).