


35 31 041

Replacing spring for clutch pedal

**Necessary preliminary tasks:**

- Remove [trim panel for pedal mechanism](#).



Disconnect return spring (1).