


SsangYong Musso fuse box diagrams


The location of the fuse box



SsangYong Musso – fuse box diagram – location

- 1. Interior Relay Box
- 2. Interior Fuse Box
- 3. Engine Compartment Fuse and Relay Box

The instrument panel fuse panel




SsangYong Musso – fuse box diagram – instrument panel

Nº	A	Description
1	15	ABS, ABD
2	20	Sun Roof
3	10	Air Bag
4	15	Audio, Clock, Out Side Mirror
5	30	Cigarette lighter, Power Socket

6	30	Heater
7	15	Door Lock
8	30	Rear Heated
9	10	Audio, Buzzer, Chime, Clock
10	30	Power Window
11	10	Immobilizer
12	20	T/C
13	15	Interior Lamp
14	15	Hazard Lamp
15	15	Stop Lamp
16	15	Turn signal Lamp, Head Lamp
17	10	Back up Lamp
18	15	Cluster, STICS
19	15	A/T, Diagnosis
20	15	Over Voltage Protection Relay (Gasolin Only)
21	15	Seat Heater
22	15	ECS
23	15	Front Wiper & Washer
24	10	Rear Wiper & Washer, A/C
Relays		
25		Front Wiper
26		ABS Warning Lamp
27		Flasher Unit
28		Fuel Pump (Gasoline Only)
29		Shift Lock (A/T)
30		Clutch Interlock & Neutral
31		Sun Roof
32		A/T 'B' Interlock (MB A/T)
33		Power Window
34		Rear Fog Lamp
35		ECS

Engine compartment fuse and relay box



SsangYong Musso – fuse box diagram – engine

compartment

Nº	A	Description
39	10	Tail Lamp
40	15	Head Lamp(LH)
41	15	Head Lamp(RH)
42	15	Front Fog Lamp
43	10	Horn
44	10	Compressor
Relays		
36		Compressor (Diesel E/G) Condenser Fan (Gasoline E/G)
37		Condenser Fan
38		Air Conditioner
45		Resistor with Diode (Gasoline E/G)
46		Front fog Lamp
47		Condenser Fan
48		Tail Lamp
49		Horn

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.