


## F RELAY LOCATIONS


② : Engine Room R/B No.2

○ : Engine Room J/B No.2

Engine Compartment Left (See Page 20)

(Gasoline)





## F RELAY LOCATIONS

|                          |                                       |
|--------------------------|---------------------------------------|
| ② : Engine Room R/B No.2 | Engine Compartment Left (See Page 20) |
| ○ : Engine Room J/B No.2 |                                       |

(Diesel)

