

Last Modified: 11-27-2007		1.6 S
Service Category: Engine/Hybrid System	Section: Cruise Control	
Model Year: 2008	Model: LX570	Doc ID: RM000000PLQ031X
Title: CRUISE CONTROL: CRUISE CONTROL SYSTEM: DIAGNOSTIC TROUBLE CODE CHART (2008 LX570)		

DIAGNOSTIC TROUBLE CODE CHART

HINT:

If a trouble code is output during the DTC check, inspect the trouble areas listed for that code. For details of the code, refer to the "See page" below.

Cruise Control System

DTC CODE	DETECTION ITEM	TROUBLE AREA	SEE PAGE
P0500	Vehicle Speed Sensor Malfunction	- Vehicle speed sensor signal circuit - Vehicle speed sensor - Combination meter - ECM	INFO
P0503	Vehicle Speed Sensor "A" Intermittent / Erratic / High	- Vehicle speed sensor - Vehicle speed sensor signal circuit - ECM - Combination meter	INFO
P0571	Brake Switch "A" Circuit	- Stop light switch - Stop light switch circuit - ECM	INFO
P0575	Cruise Control Input Circuit	ECM	INFO

