

Dodge Magnum 2005 fuse box diagram

Front Power Distribution Center

A power distribution center is located in the engine compartment. Interior Fuses

Cavity	Ampere rating [A]	Description
1	20	Left High Beam Headlight
2	20	Right High Beam Headlight
3	15	Adjustable Pedal
4	20	Horn
5	25	Headlamp Washer — If Equipped
6	15	Front Control Module (FCM)
7	20	Fog Lamp
8	15	Park Lamp
9	15	Non ABS Brakes
10	5	Starter
11	15	Auto Shutdown/Powertrain Control Module (PCM)
12	—	—

13	—	—
14	20	Powertrain Control Module
15	20	Injectors, Ignition Coils
16	20	Powertrain Control Module
17	30	Antilock Brake System (ABS) Valves
18	30	Windshield Wiper/Washer
19	50	Radiator Fan
20	20	Starter
21	50	ABS Pump Motor
22	40	Radiator Fan High/Low
23	50	High Intensity Lighting
24	—	—
25	30	Lighting Left High Beam/Right Low Beam
26	20	Transmission
27	30	Lighting Left Low Beam/Right High Beam

Rear Power Distribution Center

There is also a power distribution center located in the trunk under the spare tire access panel.

Cavity	Ampere rating [A]	Description
1	60	Ignition Off Draw
2	40	Battery
3	—	—
4	40	Battery
5	30	Heated Seat/Steering Column
6	20	Fuel Pump
7	—	—
8	15	Ignition Start/Run – Start
9	20	Console Power Outlet
10	10	Rear Fog Lamp – If Equipped
11	25	Memory Module/Door Locks
12	25	Passenger Power Seat

13	30	Door Module Run/Acc/Delay
14	10	Sentry Key/Remote Keyless Entry/Cluster
15	20	Brake Light (5.7L)
16	20	Power Outlet Trunk – if equipped
17	–	–
18	20	Selectable Power Outlet
19	10	Stop Lamp
20	20	Rear Wiper – If Equipped
21	–	–
22	–	–
23	–	–
24	–	–
25	–	–
26	–	–
27	10	Airbag/Occupant Classification Module

28	10	Curtain Airbag – if equipped
29	5	Sentry Key/Remote Keyless Entry/Powertrain Control Module Ignition Feed
30	10	Steering Column Module/Power Mirrors – if equipped
31	—	—
32	—	—
33	—	—
34	—	—
35	5	Power Antenna/Garage Door Opener/Ignition Delay
36	20	Radio/Navigation
37	15	Transmission
38	5	Analog Clock/Garage Door Opener
39	10	Heated Mirror
40	5	Power Mirror
41	10	Climate Control Module/Headlamp Leveling – if equipped/Rear Park Assist – if equipped/Tire Pressure Monitoring – if equipped
42	30	Automatic Temperature Control (ATC) Blower Motor

43	30	Rear Defroster
44	20	Audio Amplifier