


Chevrolet Lumina 1993 fuse box diagram


Glove Box Fuse Block



Chevrolet Lumina – fuse box – glove box

Fuse	Ampere rating [A]	Circuit protected
1	10	Radio & Clock
2	15	Radio & Clock; Passive Restraint Lockout; Delco Bose Amplifier
3	15	Door Lock; Courtesy, Glove Box, Underhood, Trunk, Modular Dim Lights; Lighted Visor Mirror
4	25	Windshield Wiper & Washer
5	10	Temp Door Motor; HVAC & Rear Defogger; DRL Module (Canada)
6	15	Brake Lights; ABS Control Modul
7	15	ECM
8	20	Taillights; Radio & Clock HVAC; Chime Module; DRL Module (Canada)
9	15	Hazard Warning Flashe
10	10	Rear Defogger Timer Relay; Instrument Cluster; Chime Module; Cruise Control; DIU Module (Canada); ABS Lamp Driver
11	5	Instrument Panel and Switch Lights
12	25	HVAC
13	10	Turn Signals/Flasher
14	—	—
15	10	ABS Control Module
16	—	—
17	—	—
18	—	—


Component Center



Chevrolet Lumina – fuse box – component center

Fuse	Ampere rating [A]	Usage
1		Defogger Timer Relay
2		Air Conditioner Blower Relay (HI)
3		Air Conditioner Blower Relay (LO)
4	30	Rear Defogger and HVAC Circuit Breaker
5	30	Power Door Lock Circuit Breaker
6	30	Power Window Circuit Breaker
7	20	Headlight Circuit Breaker
8	—	—
9		Hazard Flasher
10		Chime Module
11	—	—

Passenger Side Underhood Electrical Center



Chevrolet Lumina – fuse box – passenger side

underhood electrical center


Fuse	Ampere rating [A]	Usage
1	20	AIR Pump (3.4L Manual)
2	15	Trunk Release, Back-up Lights (Auto)
3	20	ECM; Fuel Pump
4	—	—
5	—	—
6	—	—
7	10	Direct Ignition System
8	10	Fuel Injectors
9	—	—
10	15	A/C, SOL EGR (2.2L), Secondary Cooling Fan, Generator, Digital EGR, Purge Canister, Back-up Lights (3.4L Manual)
11	10	TCC; AIR Pump (3.4L Manual) ; Primary Cooling Fan (3.1 L)

Relay	Ampere rating [A]	Usage
-------	-------------------	-------

12		Fuel Pump
13		AIR Pump (3.4L)
14		Secondary Cooling Fan
15		Primary Cooling Fan
16		A/C Clutch

Fusible	Ampere rating [A]	Usage
17	60	Starter Solenoid
18	30	Cooling Fan (2.2L, 3.1L)
	60	Cooling Fan (3.4L)
19	60	Blower Motor
20	60	Cooling Fan
21	30	Fuse Block

Driver Side Underhood Electrical Center



Chevrolet Lumina – fuse box – driver side

underhood electrical center

Fuse	Ampere rating [A]	Usage
1	—	—
2	—	—
3	60	ABS Controller
4	50	Exterior Lights
5	15	Horn
6	5	ABS
7	—	—
8	—	—
9	—	—
10	—	—
11	—	—
12	—	—
13	—	—

14	—	—
----	---	---

Relay	Usage
15	Horns
16	—
17	ABS