



BATTERY
SBF-1
MAIN SBF
SBF-6
RELAY BLOCK
20A
OP
WP
IGNITION SWITCH
IG RELAY 1 (PUSH BUTTON START)
No.33
B435
B439
LH
RH
OP : WITHOUT PUSH BUTTON START
WP : WITH PUSH BUTTON START
LH : LHD MODEL
RH : RHD MODEL
E
B248
B247
B301
13
18
15
12
ABSCM & H/U
MOTOR RELAY
VALVE RELAY
SOLENOID VALVE
FL INLET
FL OUTLET
FR INLET
FR OUTLET
RL INLET
RL OUTLET
RR INLET
RR OUTLET
PUMP MOTOR
M


B435
B439
1 2 3 4 5


B301
12 13 14 15
1 2 3 4 5 6 7 8 9 10 11
16 17 18 19 20 21 22 23 24 25 26

ABS01059