

MAIN FUSE
BOX(M/B)

B: (B143)

C: (F35)

E: (F36)

MAIN FAN
MOTOR

(F17)

MAIN FAN
RELAY 1

THROUGH JOINT
CONNECTOR

(F109)

(B360)

RELAY HOLDER

(F27)

MAIN FAN
RELAY 2

SUB FAN
RELAY

THROUGH JOINT
CONNECTOR

(F16)

(F108)

(B361)

OA : WITHOUT A/C MODEL
WA : WITH A/C MODEL

(B135) ECM

SUB FAN MOTOR

(F16)

(B361)





(B360)

(F108)

(F109)

(F27)


(F17)




B: (B135)



B: (B143)



C: (F35)



E: (F36)

