

DATA LINK CONNECTOR
BODY INTEGRATED UNIT (CAN COMMUNICATION)
COMBINATION METER
MALFUNCTION INDICATOR LIGHT
OIL PRESSURE WARNING LIGHT
I/F
POWER SUPPLY CIRCUIT
TACHO-METER
CAN TRANSCEIVER & RECEIVER
MICRO COMPUTER
BODY INTEGRATED UNIT (CAN COMMUNICATION)
IGNITION COIL No. 1
IGNITION COIL No. 2
IGNITION COIL No. 3
IGNITION COIL No. 4
STOP LIGHT & BRAKE SWITCH
CRUISE CONTROL SWITCH
TEST MODE SUB CONNECTOR
DELIVERY (TEST) MODE CONNECTOR
AT
NEUTRAL POSITION SWITCH
MT
JOINT CONNECTOR
ENGINE COOLANT TEMPERATURE INDICATOR
DRIVE CIRCUIT
ENGINE COOLANT TEMPERATURE WARNING LIGHT
OIL PRESSURE SWITCH
JOINT GROUND CONNECTOR
ACCELERATOR PEDAL POSITION SENSOR
JOINT CONNECTOR
ECM
ENGINE COOLANT TEMPERATURE SENSOR
MANIFOLD ABSOLUTE PRESSURE SENSOR
ELECTRONIC THROTTLE CONTROL
KNOCK SENSOR
CRANKSHAFT POSITION SENSOR
OIL FLOW CONTROL SOLENOID VALVE LH
OIL FLOW CONTROL SOLENOID VALVE RH
CAMSHAFT POSITION SENSOR LH
CAMSHAFT POSITION SENSOR RH
POWER STEERING OIL PRESSURE SWITCH
ENGINE GROUND
WI-17652