


TO POWER SUPPLY CIRCUIT
FB-36
F/B FUSE NO. 5
(IG)
FB-17
F/B FUSE NO. 7
(B)
FB-18
F/BFUSE NO. 7
(B)
MB-28
M/B FUSE NO. 14
(B)
OP : WITHOUT PUSH BUTTON START
*1 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4 AND 5
*2 : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 6, 7, 8, 9 AND 10
*3 : TERMINAL No. OPTIONAL ARRANGEMENT
BrW
WL
i102
R167
I/F
POWER SUPPLY CIRCUIT
DOOR WARNING LIGHT
COMBINATION METER
i10
MICRO COMPUTER
DRIVE CIRCUIT
CAN TRANSCEIVER & RECEIVER
JOINT GROUND CONNECTOR
CAN JOINT CONNECTOR
i77
i97
WB
OP
KEY WARNING SWITCH
B350
KEY ILLUMI-NATION
B224
BW
BL
BY
P
LgR
E
REF. TO GND [GND(L)-06]
A1
A9
A28
B6
D2
C23
A: i84 B: B280 C: B281 D: B279 BODY INTEGRATED UNIT


B224
B350
i97 (BLACK)
i77 (GREEN)
i102
B: B280
C: B281
D: B279
A: i84 (GRAY)
i10