


## TO POWER SUPPLY CIRCUIT

FB-36  
F/B FUSE NO. 5  
(IG)FB-17  
F/B FUSE NO. 7  
(B)FB-18  
F/B FUSE NO. 7  
(B)MB-28  
M/B FUSE NO. 14  
(B)

- OP : WITHOUT  
PUSH BUTTON START
- \*1 : TERMINAL No. OPTIONAL  
ARRANGEMENT  
AMONG 1, 2, 3, 4 AND 5
- \*2 : TERMINAL No. OPTIONAL  
ARRANGEMENT  
AMONG 6, 7, 8, 9 AND 10
- \*3 : TERMINAL No. OPTIONAL  
ARRANGEMENT

COMBINATION  
METER

i10



B224

B350

i97 (BLACK)

i77 (GREEN)

i53

B: B280

1 2

1 2 3 4

1 2 3 4 5 6 7 8

1 2 3 4 5 6 7 8 9 10

1 2 3 4 5 6 7  
8 9 10 11 12 13 14 15 161 2 3 4 5 6  
7 8 9 10 11 12 13 14 15 16 17  
18 19 20 21 22 23 24 25 26

C: B281

D: B279

A: i84 (GRAY)

i10

1 2 3 4 5 6 7  
8 9 10 11 12 13 14 15 16 17 18 19  
20 21 22 23 24 25 26 27 281 2 3 4 5 6 7  
8 9 10 11 12 13 14 15 16 17 18 19 20  
21 22 23 24 25 26 27 28 29 301 2 3 4 5 6 7 8  
9 10 11 12 13 14 15 16 17 18 19 20 21 22 23  
24 25 26 27 28 29 30 31 32 33 34 351 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20  
21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40