

Injector code registration.

Enter the injector code #1.

(1)

(3)

(5)


(7)

(2)

(4)

(6)

(8)



(1)

(3)

(5)

(7)

(2)

(4)

(6)

(8)

OK

Cancel

Injector code registration.

Enter the injector code #2.

(1)

(3)

(5)


(7)

(2)

(4)

(6)

(8)



(1)

(3)

(5)

(7)

(2)

(4)

(6)

(8)

OK

Cancel

Injector code registration.

Enter the injector code #3.

(1)

(3)

(5)


(7)

(2)

(4)

(6)

(8)



(1)

(3)

(5)

(7)

(2)

(4)

(6)

(8)

OK

Cancel

Injector code registration.

Enter the injector code #4.

(1)

(3)

(5)


(7)

(2)

(4)

(6)

(8)



(1)

(3)

(5)

(7)

(2)

(4)

(6)

(8)

OK

Cancel