

EH : EH MODEL
 EE : EXCEPT FOR EH MODEL
 4Dr : 4 DOOR MODEL
 5Dr : 5 DOOR MODEL
 *1 : EH MODEL : V
 EXCEPT FOR EH MODEL : B

TO POWER SUPPLY
 CIRCUIT
 FB-18
 F/B FUSE NO. 7
 (B)

