



- OP** : WITHOUT PUSH BUTTON START
WP : WITH PUSH BUTTON START
AC : KA, KC MODEL
***1** : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 1, 2, 3, 4 AND 5
***2** : TERMINAL No. OPTIONAL ARRANGEMENT AMONG 6, 7, 8, 9 AND 10
***3** : TERMINAL No. OPTIONAL ARRANGEMENT
***4** : WITHOUT PUSH BUTTON START : WL WITH PUSH BUTTON START : WY

