

Citroen Berlingo II Multispace (2008) – fuse box diagram

Year of production: 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016

Fascia fuses




Citroen Berlingo II Multispace – fuse box – fascia

fuses

Fuses	Ampere rating [A]	Allocation
1	15	Rear wiper
2	—	Spare
3	5	Air bag
4	10	Air conditioning, diagnostic socket, mirror control, headlamp beam
5	30	Electric windows
6	30	Locks
7	5	Rear courtesy light, front map reading light, roof console
8	20	Audio equipment, CD changer, display, tyre under-inflation detection, alarm and siren
9	30	Front and rear 12 V socket
10	15	Central column
11	15	Low current ignition switch
12	15	Rain and brightness sensor, air bag
13	5	Instrument panel
14	15	Parking assistance, automatic air conditioning controls, hands-free kit
15	30	Locks
16	—	Spare
17	40	Rear screen/mirrors de-icing

Fuse box in passenger compartment



Citroen Berlingo II Multispace – fuse box – passenger compartment

Fuses	Ampere rating [A]	Allocation
1	—	Spare
2	20	Heated seats
3	—	Spare
4	15	Folding mirrors relay
5	15	Refrigeration equipment socket relay

Fuse box under the bonnet

Fuses	Ampere rating [A]	Allocation
1	20	Engine management
2	15	Horn
3	10	Front and rear wash-wipe pump
4	20	Headlamp wash pump
5	15	Engine components
6	10	Steering wheel angle sensor, ESP
7	10	Brake switch, clutch switch
8	25	Starter
9	10	Headlamp beam motor, parc management unit
10	30	Engine components
11	40	Spare
12	30	Wipers
13	40	Built-in systems interface
14	30	Pump
15	10	Right-hand main beam headlamp
16	10	Left-hand main beam headlamp
17	15	Right-hand dipped headlamp
18	15	Left-hand dipped headlamp

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.