



D RELAY LOCATIONS


[Engine Compartment] (Gasoline)




(1CD-FTV)



[Instrument Panel] (LHD)




(RHD)




D RELAY LOCATIONS


[Body]
(S/D)



(L/B)



(W/G)



cardiagn.com


D RELAY LOCATIONS

① : Engine Room R/B No.1
 ○ : Engine Room J/B No.1

Engine Compartment Left (See Page 8)

(Gasoline)

* 1: 2AZ-FSE, 1AZ-FSE, 1AZ-FE
 * 2: 1ZZ-FE, 3ZZ-FE




① : Engine Room R/B No.1

○ : Engine Room J/B No.1


Engine Compartment Left (See Page 8)

(1CD-FTV)




D RELAY LOCATIONS

② : Engine Room R/B No.2 Near the Radiator Fan (See Page 8)



③ : Engine Room R/B No.3 Left Side of the Suspension Tower (See Page 8)
(1CD-FTV)




④ : Engine Room R/B No.4

○ : Engine Room J/B No.4

Left Side of the Suspension Tower (See Page 8)

(Gasoline)

- * 1: VSC (w/ VSC)
 ABS (w/o VSC)
 * 2: 2AZ-FSE, 1AZ-FSE, 1AZ-FE
 * 3: 1ZZ-FE, 3ZZ-FE




cardiagn.com


D RELAY LOCATIONS

⑤ : Driver Side R/B	LHD : Left Side of the Instrument Panel (See Page 9)
	RHD : Instrument Panel Reinforcement LH (See Page 9)

(LHD)



(RHD)




⑥ : Fuse Block

○ : J/B No.6

Lower Finish Panel (See Page 9)


- * 1:P-RR P/W (LHD)
D-RR P/W (RHD)
- * 2:P-FR P/W (LHD)
D-FR P/W (RHD)
- * 3:D-RR P/W (LHD)
P-RR P/W (RHD)
- * 4:D-FR P/W (LHD)
P-FR P/W (RHD)




D RELAY LOCATIONS

○ : Driver Side J/B


Left Side of the Instrument Panel (See Page 9)






D RELAY LOCATIONS

[Driver Side J/B Inner Circuit]




(Cont. Next Page)




D RELAY LOCATIONS

○ : Center J/B


Instrument Panel Reinforcement RH (See Page 9)





D RELAY LOCATIONS

[Center J/B Inner Circuit]



(Cont. Next Page)

(Cont'd)

