


Fuses are located to right side of steering wheel behind storage compartment.



Nº	A	Description
1	10	Left Headlight Low Beam
2	10	Right Headlight Low Beam
3	10	Instrument & License Lights
4	15	Rear Window Wiper/Washer, Heated Front Seats
5	15	Windshield Wiper/Washer, Rear Window Washer, Heated Washer Jets
6	30	A/C, Fresh Air Fan
7	10	Right Tail Light & Side Marker Light, Engine Compartment Lamp
8	10	Left Taillight & Side Marker Light
9	20	Rear Window & Mirror Heater
10	15	Fog Lamps
11	10	Left Headlight High Beam & High Beam Indicator
12	10	Right Headlight High Beam
13	10	Horn, Radiator Cooling Fan
14	10	Backup Lights, Electric Mirrors, Heated Front Seats, Windshield Washer Jets, Cruise Control, Pow
15	10	Engine Electronics
16	15	Warning/Indicator Lights, Multi-Function Indicator, Glove Box Light, ABS
17	10	Turn Signals

18	20	Fuel Pump
19	30	A/C, Radiator Cooling Fan
20	10	Brake Lights
21	15	Dome & Luggage Lamps, Clock, Radio, Central Locking System, Multi-Function Indicator, Vanity
22	10	Cigarette Lighter
Relay		
1		A/C Control Module Relay
2		Rear Window Wiper/Washer Relay
3		ECM Power Supply Relay
4		Load Reduction Relay
5		Open
6		Emergency Flasher Relay
7		Headlight Washer Relay
8		Washer/Wiper Intermittent Relay
9		Seat Belt Warning Relay
10		Fog Lamp/Parking Lamp Relay
11		Dual Horn Relay
12		Fuel Pump Relay
13		Heater Control Module Relay
14		Coolant Pump After-Run Relay
15		Open
16		Open
17		Open
18		Roof Ventilator Fan (Fuse)
19		Heater Air Blower Relay
20		Starter Interlock/Back-up Light Relay
21	5	Back-up Lights, Cruise Control
22	20	A/C (Second Evaporator)
23		Rear Window Defroster/Heated Mirror Relay
24	20	Power Windows, Central Locking System
25	10	ABS System
26	15	Rear Window Defroster, Heated Mirrors
27		A/C Compressor Clutch Relay

Additional Fuse Identification

Located on left side of engine compartment, above battery.

1	50	Radiator Fan
---	----	--------------

Located in the engine compartment, above the brake booster.

1	50	Glow Plugs (1995 Diesel Models Only)
---	----	--------------------------------------

Located under drivers seat

1	25	Auxiliary HVAC Fan
2	20	Blower for Auxiliary Heater

3	30	Refrigerator Socket, Socket below Folding Table (MV Models)
4	5	Fluorescent Light (MV Models)