

6120 Overview of tightening torques

Battery rollover protection bracket to luggage compartment floor		
Screw	Tightening torque	8Nm
Negative battery terminal		
Nut	Tightening torque	5Nm
Negative battery terminal 12V dual storage system		
Nut	Tightening torque	19Nm
Positive battery cable (12 V dual storage system)		
Nut M8	Tightening torque	19Nm
Positive battery terminal		
Nut	Tightening torque	5Nm

6121 Overview of tightening torques

Battery holder to body			
M8 screw		Tightening torque	15Nm
Retaining bracket 12 V dual storage system			
Nut M8		Tightening torque	15Nm
Rollover protection bar auxiliary battery on holder			
Nut M8		Tightening torque	15Nm

cardiagn.com

6131 Overview of tightening torques

Controller to gear selector switch			
Screw		Tightening torque	1,8Nm
Gear selector switch to centre console trim			
Screw		Tightening torque	1,8Nm
Roof function centre			
		Tightening torque	1,2Nm
Shift paddle to steering wheel			
Screw TS5x12		Tightening torque	2Nm
Steering column switch cluster (SZL) on the steering column			
Screw TS5x20		Tightening torque	3Nm

6133 Overview of tightening torques

Fanfare to support for bumper panel		
M6x20 screw	Tightening torque	8,8Nm

cardiagn.com

6161 Overview of Technical Data

Distance from window pane edge to wiper blade	
	Wiper arm right (A)
	57,5 ± 5 mm
	Wiper arm left (B)
	63,3 ± 4 mm

cardiagn.com

6161 Overview of tightening torques

Windscreen wiper arm		
Combination hexagon nut	Tightening torque	35Nm
Wiper console to body		
Nut M8 Renew nut.	Tightening torque	11,8Nm

cardiagn.com

61 operating fluid overview

Expendable materials

Protective cover "Vehicle protection" picture panel		8319 2 350 087
--	--	----------------

cardiagn.com