

Dodge Magnum 2006 fuse box diagram

Front Power Distribution Center

A power distribution center is located in the engine compartment. Interior Fuses

Cavity	Ampere rating [A]	Description
1	—	—
2	—	—
3	15	Adjustable Pedals – if equipped
4	20	AC Clutch/Horn
5	—	—
6	15	Front Control Module (FCM)
7	20	Fog Lamp
8	15	Lights – License, Park, Side Marker, Stop, Turn
9	15	Front Control Module (FCM)
10	5	Powertrain Control Module (PCM)/Starter
11	20	Auto Shutdown/Powertrain Control Module (PCM)
12	—	—

13	—	—
14	25	Powertrain Control Module (PCM)
15	25	Injectors, Ignition Coils
16	—	—
17	30	Antilock Brakes System (ABS) Valves/Powertrain Control Module (PCM)
18	30	Windshield Wiper/Washer
19	50	Radiator Fan
20	20	Starter
21	50	Antilock Brakes System (ABS) Pump Motor
22	40	AC Clutch/Radiator Fan High — Low
23	—	—
24	60	Radiator Fan — AWD
25	30	Front Control Module (FCM)
26	20	Transmission — RLE
27	30	Front Control Module (FCM)

Rear Power Distribution Center

There is also a power distribution center located in the trunk under the spare tire access panel.

Cavity	Ampere rating [A]	Description
1	60	Ignition Off Draw (IOD)
2	40	Battery
3	—	—
4	40	Battery
5	30	Heated Seats – if equipped
6	20	Fuel Pump
7	—	—
8	15	Ignition Switch/Occupant Classification Module (OCM)
9	20	Console Power Outlet
10	—	—
11	25	Cluster – without power memory seat/Driver Seat Switch – with power memory seat/Memory Module – if equipped
12	25	Passenger Power Seat

13	25	Door Modules – except base/Driver Door Lock Switch – base/ Driver Express Power Window Switch – if equipped/Passenger Door Lock Switch – base
14	10	AC Heater Control/Cluster/Sentry Key Remote Keyless Entry
15	20	Trailer Tow Brake Module – if equipped
16	20	Rear Power Outlet
17	20	Cluster
18	20	Selectable Power Outlet
19	10	Stop Lights
20	20	Rear Wiper – if equipped
21	—	—
22	—	—
23	—	—
24	—	—
25	—	—
26	—	—
27	10	Airbag/Occupant Classification Module

28	10	Curtain Airbag – if equipped
29	5	Antilock Brakes Module/Cluster/Front Control Module (FCM)/Powertrain Control Module (PCM)/Sentry Key Remote Keyless Entry/Stop Lights
30	10	Door Modules/Power Mirrors – if equipped/Steering Control Module
31	—	—
32	—	—
33	—	—
34	—	—
35	5	Amplifier – if equipped/Antenna/Ignition Delay/Overhead Console – if equipped/Passenger Door Lock & Express Power Window Switch – if equipped/Power Mirrors – if equipped/Rear Defrost
36	20	Hands Free Phone – if equipped/Media System Monitor DVD – if equipped/Radio/Satellite Receiver – if equipped
37	15	Transmission – NAG1
38	5	Analog Clock/Overhead Console – if equipped
39	10	Heated Mirrors – if equipped
40	5	Heated Seats – if equipped/Inside Rearview Mirror/Manual Temperature Control (early build) – if equipped

41	10	AC Heater Control (except early build MTC)/Tire Pressure Monitoring – if equipped
42	30	Front Blower Motor
43	30	Amplifier – if equipped/Antenna/Rear Defrost
44	20	Amplifier – if equipped/Front Control Module (FCM)/Sunroof – if equipped