

2000 Suzuki Swift Alarm, Remote Start, Keyless Entry Wiring Information		
Constant 12V+	White	Ignition Switch Harness
Starter	Red/Yellow	Ignition Switch Harness
Ignition	Blue/Black	Ignition Switch Harness
Ignition 2	Blue/Red	Ignition Switch Harness
Accessory	Red/Green	Ignition Switch Harness
Tach	Brown	Coil
Brake Switch	Green/White	Brake Switch
Trunk Pin	Black/Yellow (-)	Switch or at Light
Parking Lights	Red/Yellow	Light Switch
Head Lamp	Red/White (-)	Light Switch use Relay
Hood Pin	n/a	
Factory Disarm	n/a	
Door Trigger	Black/Red (-)	Driver's Kick Panel
Door Lock	Pink	Driver's Kick Panel
Door Unlock	Pink/Black	
Horn Wire	Blue/Green (-)	Or Green (-) at Steering Column