



Warranty Bulletin

ISSUE NO	BF-WB-A-006
DATE	16 th Feb 2015
PAGE	01 of 01

SUBJECT	: INTRODUCTION OF OPERATION ITEM AND FLAT RATE TIME
APPLICABLE MODEL	: CIAZ (AVB414)
APPLICABLE SPECIFICATIONS	: P05 / P06 / P43 / P71 / P74 / P85 / P96

This bulletin is to inform you of the operation item and the flat rate time for the CIAZ (AVB414) produced at Maruti Suzuki India Limited in India.

UPDATE OF YOUR COMPUTER FILE

The updated data in our server is available through SCAN.

EFFECTIVE DATE

The updated flat rate time will be effective to the warranty claims processed by Maruti Suzuki India Limited on and after 1st Jan, 2015.

DETAILS OF THE UPDATED OPERATION ITEM

Refer to the attached sheets (Annexure-1)

All concerned may kindly be informed.

T Udayaraj

Assistant General Manager
Literature Development &
Export Service Department

MODEL: Ciaz (AVB414)
FRM MODEL CODE: BS56

Annexure - 1

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
ENGINE ASSY		AA			
ENGINE ASSY	R&R	AA01R0		-	
FOR DOHC	R&R	AA01R1		5.7	
FOR DIESEL	R&R	AA01R2		5.8	
ENGINE ASSY	OH	AA02H0		-	
FOR DOHC	OH	AA02H2		17.6	
FOR DIESEL	OH	AA02H3		16.7	
SHORT ENGINE ASSY	R&R	AA03R0		-	
FOR DOHC	R&R	AA03R2		9.9	
FOR DIESEL	R&R	AA03R4		11.4	
OTHER		AA9999		*	
CYLINDER HEAD		AB			
CYLINDER HEAD ASSY (WITHOUT ALL VALVES)	R&R	AB03R0		-	
FOR DOHC	R&R	AB03R2		12.1	
FOR DIESEL	R&R	AB03R4		13.3	
CYLINDER HEAD GASKET	R&R	AB06R0		-	
FOR DOHC	R&R	AB06R2		7.7	
FOR DIESEL	R&R	AB06R4		10.7	
CYLINDER HEAD COVER AND/OR GASKET	R&R	AB07R0		0.8	
FOR DIESEL	R&R	AB07R1		8.7	
ENGINE COVER OR SURGE TANK COVER	R&R	AB28R0		-	
FOR DIESEL	R&R	AB28R1		0.1	
CAMSHAFT HOUSING GASKET	R&R	AB29R0		-	
FOR DIESEL	R&R	AB29R1		8.2	
ENGINE UNDER COVER (ALL)	R&R	AB30R0		0.2	
OTHER		AB9999		*	
CYLINDER		AC			
CYLINDER BLOCK	R&R	AC02R0		-	
FOR DOHC	R&R	AC02R2		11.1	
FOR DIESEL	R&R	AC02R4		13.1	
OIL PRESSURE SENSOR OR OIL PRESSURE SWITCH ASSY	R&R	AC15R0		0.2	
FOR DIESEL	R&R	AC15R1		0.2	
OIL LEVEL GAUGE GUIDE AND/OR GASKET	R&R	AC34R0		0.4	
OTHER		AC9999		*	
OIL PAN		AD			
OIL PAN AND/OR GASKET	R&R	AD01R0		1.1	
FOR DIESEL	R&R	AD01R3		1.2	
OTHER		AD9999		*	
CRANKSHAFT		AE			
CRANKSHAFT AND/OR CRANKSHAFT BEARING (ALL)	R&R	AE03R0		-	
FOR DOHC	R&R	AE03R2		10.6	
FOR DIESEL	R&R	AE03R4		12.9	
TRANSMISSION INPUT SHAFT BEARING	R&R	AE16R0		3.2	For Gasoline model
CRANKSHAFT PULLEY	R&R	AE28R0		1.0	
FOR DIESEL	R&R	AE28R1		0.4	
FLYWHEEL	R&R	AE29R0		3.2	
FOR DIESEL 2WD	R&R	AE29R3		5.4	
CRANKSHAFT FRONT OIL SEAL	R&R	AE33R0		-	
FOR DOHC	R&R	AE33R1		1.1	
FOR DIESEL	R&R	AE33R2		0.6	
CRANK REAR OIL SEAL, GASKET AND/OR CASE	R&R	AE34R0		-	
FOR AT	R&R	AE34R1		5.1	
FOR DOHC	R&R	AE34R3		4.3	
FOR DIESEL	R&R	AE34R3		5.4	
OTHER		AE9999		*	
PISTON - CONNECTING ROD		AF			
PISTON, PISTON PIN AND/OR PISTON RING (ALL)	R&R	AF01R0		-	
FOR DOHC	R&R	AF01R2		10.0	
FOR DIESEL	R&R	AF01R4		11.7	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
COMBINATION ITEM:					
CONNECTING ROD BEARING (ALL)	R&R		1	0.4	
CYLINDER HEAD ASSY AND/OR VALVE	R&R		5	4.4	For Gasoline model
CYLINDER HEAD(WITHOUT VALVE, DIESEL)	R&R		7	2.6	For Diesel model
CONNECTING ROD ASSY (ALL)	R&R	AF06R0		-	
FOR DOHC	R&R	AF06R2		10.1	
FOR DIESEL	R&R	AF06R4		11.8	
CONNECTING ROD BEARING (ALL)	R&R	AF07R0		-	
FOR DOHC	R&R	AF07R2		9.8	
FOR DIESEL	R&R	AF07R3		11.7	
OTHER		AF9999		*	
VALVE MECHANISM		AG			
VALVE (ALL)	GRI	AG05G0		-	
FOR DOHC	GRI	AG05G2		11.8	
FOR DIESEL	GRI	AG05G4		13.0	
VALVE SPRING, RETAINER, VALVE STEM OIL SEAL AND/OR VALVE COTTER (ALL)	R&R	AG06R0		-	
FOR DOHC	R&R	AG06R2		9.6	
FOR DIESEL	R&R	AG06R4		11.4	
VALVE ROCKER ARM AND/OR ROCKER ARM SHAFT (ALL)	R&R	AG08R0		-	
FOR DIESEL	R&R	AG08R3		8.3	
VALVE LASH ADJUSTER OR TAPPET (ALL)	R&R	AG12R0		1.7	
FOR DIESEL	R&R	AG12R1		8.3	
VALVE GUIDE (ALL)	R&R	AG56R0		-	
FOR DOHC	R&R	AG56R2		12.8	For Gasoline model
VALVE (ALL)	R&R	AG61R0		-	
FOR DOHC	R&R	AG61R2		11.8	
FOR DIESEL	R&R	AG61R3		13.0	
OTHER		AG9999		*	
CAMSHAFT - TIMING BELT		AH			
CAMSHAFT	R&R	AH01R0		-	
FOR DOHC	R&R	AH01R1		2.1	
FOR DIESEL	R&R	AH01R2		8.7	
GENERATOR/WATER PUMP BELT TENSIONER	R&R	AH46R0		-	
FOR AUTO TYPE	R&R	AH46R1		0.4	
TIMING CHAIN, CHAIN GUIDE, CHAIN TENSIONER, TENSIONER ADJUSTER AND/OR CRANKSHAFT SPROCKET	R&R	AH54R0		6.0	
FOR DIESEL	R&R	AH54R1		7.7	
CAMSHAFT TIMING SPROCKET (ALL)	R&R	AH55R0		1.4	
FOR DIESEL	R&R	AH55R1		7.8	
OTHER		AH9999		*	
ENGINE MOUNTING		AJ			
ENGINE MOUNTING (REAR)	R&R	AJ12R0		1.6	
FOR DIESEL	R&R	AJ12R1		0.9	
ENGINE MOUNTING (RH)	R&R	AJ13R0		0.6	
FOR DIESEL	R&R	AJ13R1		0.7	
COMBINATION ITEM:					
ENGINE MOUNTING (LH)	R&R		1	0.6	
ENGINE MOUNTING (REAR, GASO, 2WD)	R&R		2	1.3	For Gasoline model
ENGINE MOUNTING (REAR, DIESEL, 2WD)	R&R		4	0.5	For Diesel model
ENGINE MOUNTING (LH)	R&R	AJ14R0		0.9	
FOR DIESEL	R&R	AJ14R1		1.1	
COMBINATION ITEM:					
ENGINE MOUNTING (REAR, GASO, 2WD)	R&R		1	1.1	For Gasoline model
ENGINE MOUNTING (REAR, DIESEL, 2WD)	R&R		3	0.5	For Diesel model
OTHER		AJ9999		*	
OIL PUMP		BA			
OIL PUMP ASSY AND/OR GASKET	R&R	BA02R0		-	
FOR DOHC	R&R	BA02R2		5.8	
FOR DIESEL	R&R	BA02R3		7.6	
OIL PUMP ASSY	OH	BA03H0		-	
FOR DOHC	OH	BA03H2		6.0	For Gasoline model
OIL CONTROL VALVE (ALL)	R&R	BA26R0		0.3	For Gasoline model
OTHER		BA9999		*	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
OIL FILTER		BB			
OIL FILTER ASSY	R&R	BB01R0		0.4	
FOR DIESEL	R&R	BB01R1		0.2	
OIL PUMP STRAINER	R&R	BB03R0		-	
FOR 2WD	R&R	BB03R1		1.2	
FOR DIESEL	R&R	BB03R2		7.6	
OIL COOLER	R&R	BB07R0		-	
FOR DIESEL	R&R	BB07R2		1.1	
OIL & AIR SEPARATOR	R&R	BB14R0		-	
FOR DIESEL	R&R	BB14R1		1.3	
OTHER		BB9999		*	
RADIATOR - HOSE		CA			
RADIATOR ASSY	R&R	CA01R0		1.4	
FOR DIESEL	R&R	CA01R1		1.8	
WATER RESERVOIR TANK	R&R	CA04R0		0.2	
FOR DIESEL	R&R	CA04R1		0.6	
RADIATOR CAP	R&R	CA06R0		0.2	
WATER THERMOSTAT AND/OR GASKET	R&R	CA10R0		-	
FOR DOHC	R&R	CA10R1		0.6	
FOR DIESEL	R&R	CA10R2		1.1	
RADIATOR INLET HOSE AND/OR CLAMP	R&R	CA12R0		0.6	
FOR DIESEL	R&R	CA12R1		0.6	
RADIATOR OUTLET HOSE AND/OR CLAMP	R&R	CA13R0		0.6	
FOR DIESEL	R&R	CA13R1		0.7	
HEATER INLET HOSE AND/OR CLAMP	R&R	CA15R0		0.6	
FOR DIESEL	R&R	CA15R1		0.9	
HEATER OUTLET HOSE AND/OR CLAMP	R&R	CA16R0		0.7	
FOR DIESEL	R&R	CA16R1		0.8	
WATER BY-PASS HOSE, THROTTLE BODY HOSE AND/OR CLAMP	R&R	CA17R0		0.6	For Gasoline model
THERMOSTAT CASE	R&R	CA46R0		1.5	For Gasoline model
WATER INLET PIPE AND/OR O-RING	R&R	CA58R0		1.3	
FOR DIESEL	R&R	CA58R1		1.5	
HEATER OUTLET PIPE	R&R	CA59R0		-	
FOR DIESEL	R&R	CA59R1		1.1	
OTHER		CA9999		*	
FAN		CB			
RADIATOR FAN ASSY	R&R	CB01R0		0.8	
FOR DIESEL	R&R	CB01R1		1.0	
WATER PUMP ASSY AND/OR GASKET	R&R	CB15R0		-	
FOR DOHC	R&R	CB15R1		1.2	
FOR DIESEL	R&R	CB15R2		1.0	
WATER PUMP PULLEY	R&R	CB23R0		0.4	For Gasoline model
GENERATOR/WATER PUMP BELT (GASOLINE)	R&R	CB34R0		0.7	
COMBINATION ITEM:					
CRANKSHAFT PULLEY	R&R		1	0.3	
GENERATOR PULLEY	R&R		2	0.6	
WATER PUMP PULLEY	R&R		3	0.1	
GENERATOR/WATER PUMP BELT (DIESEL)	R&R	CB35R0		-	
FOR AUTO TYPE	R&R	CB35R1		0.3	
COMBINATION ITEM:					
CRANKSHAFT PULLEY	R&R		1	0.1	
GENERATOR PULLEY	R&R		2	1.1	
GENERATOR/WATER PUMP BELT TENSIONER	R&R		5	0.1	
OTHER		CB9999		*	
MANIFOLD - MUFFLER		DA			
INTAKE MANIFOLD	R&R	DA01R0		-	
FOR DOHC	R&R	DA01R2		0.9	
FOR DIESEL	R&R	DA01R3		2.5	
INTAKE MANIFOLD GASKET	R&R	DA03R0		-	
FOR DOHC	R&R	DA03R2		0.9	
FOR DIESEL	R&R	DA03R3		2.4	
EXHAUST MANIFOLD ASSY	R&R	DA09R0		-	
FOR DOHC (V-TYPE:BOTH SIDES)	R&R	DA09R2		0.9	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
FOR DIESEL	R&R	DA09R3		1.7	
EXHAUST MANIFOLD GASKET	R&R	DA10R0		-	
FOR DOHC	R&R	DA10R3		0.9	
FOR DIESEL	R&R	DA10R4		1.7	
EXHAUST PIPE NO.1	R&R	DA12R0		0.4	
FOR DIESEL	R&R	DA12R1		0.4	
EXHAUST PIPE NO.2	R&R	DA13R0		0.5	
FOR DIESEL	R&R	DA13R1		0.5	
EXHAUST PIPE GASKET OR EXHAUST PIPE SEALRING	R&R	DA19R0		0.5	
EXHAUST PIPE MOUNTING RUBBER AND/OR MUFFLER MOUNTING RUBBER (ONE)	R&R	DA37R0		0.3	
COMBINATION ITEM: ONE OR MORE ADDITIONAL	R&R		1	0.1	
EXHAUST MUFFLER (ONE SIDE)	R&R	DA40R0		0.4	
A/F SENSOR, FRONT O2 SENSOR OR UEGO SENSOR	R&R	DA92R0		0.3	
FOR DIESEL	R&R	DA92R1		0.5	
COMBINATION ITEM: REAR O2 SENSOR	R&R		1	0.2	For Gasoline model
REAR O2 SENSOR	R&R	DA93R0		0.4	For Gasoline model
CATALYTIC CONVERTER	R&R	DA94R0		-	
FOR DIESEL	R&R	DA94R2		1.5	
OTHER		DA9999		*	
AIR CLEANER		DB			
AIR CLEANER ASSY	R&R	DB01R0		0.4	
FOR DIESEL	R&R	DB01R1		0.4	
AIR CLEANER ELEMENT	R&R	DB05R0		0.2	
FOR DIESEL	R&R	DB05R1		0.2	
INTAKE AIR TEMPERATURE SENSOR	R&R	DB15R0		0.3	For Gasoline model
OTHER		DB9999		*	
FUEL INJECTION - NOZZLE		DD			
FUEL INJECTOR OR INJECTOR HOLDER (ALL)	R&R	DD01R0		-	
FOR DOHC	R&R	DD01R1		0.6	
FOR DIESEL	R&R	DD01R2		1.1	
DELIVERY PIPE SET	R&R	DD03R0		-	
FOR DOHC	R&R	DD03R1		0.6	
FOR DIESEL	R&R	DD03R3		0.9	
INJECTION PUMP ASSY OR HIGH PRESSURE FUEL PUMP ASSY	R&R	DD08R0		-	
FOR DIESEL	R&R	DD08R1		1.1	
FUEL PRESSURE SENSOR	R&R	DD13R0		-	
FOR DIESEL	R&R	DD13R1		0.6	
OTHER		DD9999		*	
TURBO CHARGER - INTER COOLER		DE			
TURBO CHARGER ASSY	R&R	DE01R0		-	
FOR DIESEL	R&R	DE01R1		1.5	
TURBO OIL INTAKE PIPE	R&R	DE03R0		-	
FOR DIESEL	R&R	DE03R1		0.2	
TURBO OIL DRAIN JOINT, PIPE AND/OR GASKET	R&R	DE05R0		-	
FOR DIESEL	R&R	DE05R1		1.3	
TURBO OUT AIR PIPE AND/OR GASKET	R&R	DE08R0		-	
FOR DIESEL	R&R	DE08R1		0.2	
INTER COOLER	R&R	DE10R0		-	
FOR DIESEL	R&R	DE10R1		0.7	
INTER COOLER INLET HOSE	R&R	DE16R0		-	
FOR DIESEL	R&R	DE16R1		0.5	
INTER COOLER OUTLET PIPE	R&R	DE18R0		-	
FOR DIESEL	R&R	DE18R1		0.3	
EXHAUST MANIFOLD TURBO GASKET	R&R	DE28R0		-	
FOR DIESEL	R&R	DE28R1		1.4	
INTER COOLER OUTLET NO.1 HOSE	R&R	DE29R0		-	
FOR DIESEL	R&R	DE29R1		0.5	
INTER COOLER OUTLET NO.2 HOSE	R&R	DE30R0		-	
FOR DIESEL	R&R	DE30R1		0.3	
OTHER		DE9999		*	

OPERATION	OPERATION NUMBER		FLAT RATE TIME	REMARKS
	BASIC CODE	V/C CODE		
FUEL PUMP	DF			
ELECTRICAL FUEL PUMP ASSY R&R	DF04R0		1.2	FLAT RATE TIME IS UPDATED
OTHER	DF9999		*	
FUEL FILTER	DG			
FUEL FILTER ASSY OR ELEMENT R&R	DG01R0		0.6	
FOR ELECTRONIC FUEL INJECTION DIESEL R&R	DG01R2		0.7	
OTHER	DG9999		*	
FUEL TANK	DH			
FUEL TANK ASSY R&R	DH01R0		1.3	
FUEL LEVEL GAUGE ASSY AND/OR GASKET R&R	DH07R0		1.2	FLAT RATE TIME IS UPDATED
FUEL TANK FILLER HOSE R&R	DH48R0		0.5	
FUEL FILLER NECK ASSY R&R	DH49R0		0.7	
OTHER	DH9999		*	
AIR FLOW METER - THROTTLE BODY	DJ			
MASS AIR FLOW SENSOR AND/OR GASKET R&R	DJ02R0		-	
FOR DIESEL R&R	DJ02R1		0.5	
THROTTLE BODY ASSY AND/OR GASKET R&R	DJ06R0		-	
FOR DOHC R&R	DJ06R1		0.9	For Gasoline model
ENGINE COOLANT TEMPERATURE SENSOR R&R	DJ14R0		0.6	
FOR DIESEL R&R	DJ14R1		1.0	
ACCELERATOR PEDAL POSITION SENSOR OR ACCELERATOR PEDAL ASSY R&R	DJ21R0		0.4	
OTHER	DJ9999		*	
BATTERY	EA			
BATTERY R&R	EA01R0		0.3	
MAIN FUSE ASSY OR FUSIBLE LINK ASSY R&R	EA03R0		0.3	
BATTERY GROUND CABLE R&R	EA08R0		0.5	For Gasoline model
CURRENT SENSOR ASSY R&R	EA09R0		0.3	For Gasoline model
OTHER	EA9999		*	
COIL - IGNITER - SPARK PLUG	EB			
IGNITION COIL ASSY R&R	EB01R0		0.4	For Gasoline model
SPARK PLUG (ALL) R&R	EB21R0		0.5	For Gasoline model
GLOW PLUG (ALL) R&R	EB29R0		0.4	
GLOW PLUG CONTROL MODULE R&R	EB36R0		0.7	
OTHER	EB9999		*	
DISTRIBUTOR	ED			
CAMSHAFT POSITION SENSOR R&R	ED12R0		0.3	
FOR DIESEL R&R	ED12R1		0.4	
OTHER	ED9999		*	
STARTING MOTOR	EE			
STARTING MOTOR ASSY R&R	EE01R0		-	
FOR DOHC R&R	EE01R1		0.6	
FOR DIESEL R&R	EE01R2		0.9	
STARTING MOTOR ASSY OH	EE02H0		-	
FOR DOHC OH	EE02H1		1.0	
FOR DIESEL OH	EE02H2		1.3	
OTHER	EE9999		*	
GENERATOR	EF			
GENERATOR ASSY R&R	EF01R0		0.9	
FOR DIESEL R&R	EF01R1		1.2	
GENERATOR ASSY OH	EF02H0		1.3	
FOR DIESEL OH	EF02H1		1.7	
GENERATOR PULLEY R&R	EF14R0		1.2	
FOR DIESEL R&R	EF14R1		1.5	
OTHER	EF9999		*	
EGR - SECOND AIR SYSTEM	FA			
EGR VALVE ASSY AND/OR GASKET R&R	FA14R0		-	
FOR DIESEL R&R	FA14R1		1.9	
EGR COOLER R&R	FA15R0		-	
FOR DIESEL R&R	FA15R1		2.0	
OTHER	FA9999		*	
OTHER DEVICES	FB			
EVAPORATIVE EMISSION CANISTER OR EVAP LEAK CHECK MODULE R&R	FB08R0		0.2	For Gasoline model

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
ENGINE CONTROL MODULE OR POWERTRAIN CONTROL MODULE	R&R	FB09R0		0.7	
FOR DIESEL	R&R	FB09R1		1.0	
COMBINATION ITEM:					
PROGRAMMING	PGM		1	0.4	
PCV VALVE	R&R	FB12R0		0.2	For Gasoline model
KNOCK SENSOR ASSY	R&R	FB13R0		0.9	For Gasoline model
MAP SENSOR (PRESSURE SENSOR)	R&R	FB17R0		0.3	
FOR DIESEL	R&R	FB17R1		0.4	
EVAP CANISTER AIR VALVE OR PURGE VALVE	R&R	FB23R0		0.3	For Gasoline model
CRANKSHAFT POSITION SENSOR (FLYWHEEL SIDE)	R&R	FB24R0		-	
FOR DIESEL	R&R	FB24R3		0.4	
CRANKSHAFT POSITION SENSOR (CRANKSHAFT PULLEY SIDE)	R&R	FB25R0		0.6	For Gasoline model
VACUUM PUMP	R&R	FB29R0		-	
FOR DIESEL	R&R	FB29R1		0.7	
ECM REPROGRAMMING	RPG	FB32P0		0.4	
TCM REPROGRAMMING	RPG	FB33P0		0.4	For Automatic transaxle model
OTHER		FB9999		*	
CLUTCH		GA			
CLUTCH COVER ASSY AND/OR CLUTCH DISC ASSY	R&R	GA01R0		3.0	
FOR DIESEL	R&R	GA01R3		5.3	
COMBINATION ITEM:					
INPUT SHAFT BEARING	R&R		1	0.2	For Gasoline model
CLUTCH RELEASE/SLAVE CYLINDER ASSY	R&R		3	0.2	
CLUTCH PEDAL	R&R	GA34R0		1.3	
CLUTCH MASTER CYLINDER ASSY	R&R	GA35R0		-	
FOR LHD GASOLINE	R&R	GA35R1		0.4	
FOR RHD GASOLINE	R&R	GA35R3		0.4	
FOR RHD DIESEL	R&R	GA35R4		0.5	
CLUTCH RELEASE/SLAVE CYLINDER ASSY	R&R	GA38R0		2.9	
FOR DIESEL	R&R	GA38R1		5.1	
CLUTCH OIL PIPE	R&R	GA75R0		-	
FOR LHD GASOLINE	R&R	GA75R2		0.3	
FOR RHD GASOLINE	R&R	GA75R4		2.1	
FOR RHD DIESEL	R&R	GA75R5		2.3	
CLUTCH RESERVOIR HOSE	R&R	GA76R0		0.3	
OTHER		GA9999		*	
TRANSAXLE (MANUAL)		GE			
TRANSAXLE ASSY	R&R	GE01R0		2.9	
FOR DIESEL	R&R	GE01R2		5.3	
COMBINATION ITEM:					
CLUTCH DISC AND/OR COVER	R&R		1	0.2	
FLYWHEEL	R&R		2	0.3	FLAT RATE TIME IS UPDATED
INPUT SHAFT BEARING	R&R		3	0.1	For Gasoline model
CLUTCH RELEASE/SLAVE CYLINDER ASSY	R&R		5	0.2	
TRANSAXLE ASSY	OH	GE02H0		6.5	
FOR DIESEL	OH	GE02H2		8.7	
COMBINATION ITEM:					
CLUTCH DISC AND/OR COVER	R&R		1	0.2	
FLYWHEEL	R&R		2	0.3	FLAT RATE TIME IS UPDATED
INPUT SHAFT BEARING	R&R		3	0.1	For Gasoline model
CLUTCH RELEASE/SLAVE CYLINDER ASSY	R&R		5	0.2	
INPUT SHAFT PARTS	R&R	GE03R0		5.5	
FOR DIESEL	R&R	GE03R2		7.7	
INPUT SHAFT OIL SEAL AND/OR O-RING	R&R	GE04R0		4.6	
FOR DIESEL	R&R	GE04R2		6.9	
COUNTER SHAFT PARTS	R&R	GE05R0		5.6	
FOR DIESEL	R&R	GE05R2		7.9	
REVERSE IDLE GEAR	R&R	GE06R0		4.5	
FOR DIESEL	R&R	GE06R2		6.8	
TRANSMISSION RH CASE	R&R	GE08R0		4.7	
FOR DIESEL	R&R	GE08R2		7.1	
TRANSMISSION LH CASE	R&R	GE09R0		4.7	
FOR DIESEL	R&R	GE09R2		7.0	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
TRANSMISSION SIDE CASE	R&R	GE10R0		0.8	
FOR DIESEL	R&R	GE10R2		0.8	
DIFFERENTIAL PINION, GEAR AND/OR CASE	R&R	GE11R0		5.5	
FOR DIESEL	R&R	GE11R2		7.9	
FINAL DRIVEN GEAR	R&R	GE12R0		4.7	
FOR DIESEL	R&R	GE12R2		7.0	
DIFFERENTIAL SIDE BEARING (ALL) AND/OR SPEEDOMETER DRIVE GEAR	R&R	GE13R0		4.8	
FOR DIESEL	R&R	GE13R2		7.1	
DIFFERENTIAL SIDE OIL SEAL (ONE SIDE)	R&R	GE14R0		1.0	
FOR DIESEL	R&R	GE14R3		1.0	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.3	
SPEEDOMETER DRIVEN GEAR OR SPEED SENSOR	R&R	GE15R0		0.8	
FOR DIESEL	R&R	GE15R3		0.8	
GEAR SHIFT FORK AND/OR SHAFT (ALL)	R&R	GE20R0		4.6	
FOR DIESEL	R&R	GE20R3		6.9	
GEAR SHIFT/SELECT SHAFT ASSY	R&R	GE25R0		0.8	
BACK UP LAMP SWITCH	R&R	GE27R0		0.5	
OTHER		GE9999		*	
TRANSAXLE (AUTOMATIC)		GF			
TRANSAXLE ASSY	R&R	GF01R0		4.5	
COMBINATION ITEM: TRANSMISSION CONTROL MODULE(TCM)	R&R		1	0.1	
TCM REPROGRAMMING	RPM		2	0.4	
TRANSAXLE ASSY	OH	GF02H0		7.6	
DRIVE PLATE	R&R	GF03R0		4.0	
TORQUE CONVERTER	R&R	GF04R0		3.9	
OIL FILLER TUBE ASSY	R&R	GF05R0		0.2	
MANUAL SHIFT SHAFT OIL SEAL OR O-RING	R&R	GF06R0		0.7	
OIL INLET HOSE AND/OR OIL OUTLET HOSE	R&R	GF08R0		0.5	
OIL PAN AND/OR GASKET	R&R	GF09R0		1.0	
OIL PUMP ASSY	R&R	GF12R0		4.4	
OIL PUMP ASSY	OH	GF13H0		4.6	
DIFFERENTIAL GEAR SET AND/OR FINAL DRIVEN GEAR	R&R	GF14R0		4.6	
DIFFERENTIAL SIDE BEARING (ALL) AND/OR SPEEDOMETER DRIVE GEAR	R&R	GF16R0		4.7	
AT TRANSMISSION VALVE BODY ASSY AND/OR INNER PARTS	R&R	GF22R0		1.5	
RIGHT DIFFERENTIAL SIDE OIL SEAL	R&R	GF38R0		1.0	
COMBINATION ITEM: LEFT DIFFERENTIAL SIDE OIL SEAL	R&R		1	0.3	
LEFT DIFFERENTIAL SIDE OIL SEAL	R&R	GF39R0		0.9	
OIL STRAINER	R&R	GF41R0		1.0	
INPUT SPEED SENSOR	R&R	GF42R0		0.4	
OUTPUT SPEED SENSOR	R&R	GF45R0		0.4	
AT VALVE BODY SOLENOID HARNESS	R&R	GF46R0		1.6	
OTHER		GF9999		*	
GEAR SHIFT LEVER (MANUAL TRANSMISSION - TRANSAXLE)		GG			
GEAR SHIFTING CONTROL LEVER	R&R	GG01R0		0.6	
LEVER KNOB	R&R	GG02R0		0.2	
CONTROL LEVER BOOT OR FLOOR CONSOLE GARNISH	R&R	GG03R0		0.2	FLAT RATE TIME IS UPDATED
GEAR SHIFT CONTROL CABLE (BOTH SIDES)	R&R	GG06R0		1.2	
OTHER		GG9999		*	
GEAR SHIFT LEVER (AUTOMATIC TRANSMISSION -TRANSAXLE)		GH			
MANUAL SELECTOR ASSY	R&R	GH01R0		0.7	
SELECT CABLE ASSY	R&R	GH02R0		0.8	
BULB (FOR POSITION INDICATOR)	R&R	GH03R0		0.2	
SHIFT LEVER SWITCH ASSY	R&R	GH04R0		0.5	
INTER LOCK CABLE	R&R	GH05R0		0.5	
SELECT LEVER KNOB ASSY	R&R	GH07R0		0.5	
OTHER		GH9999		*	
FRONT SUSPENSION (STRUT TYPE)		HA			
FRONT SUSPENSION FRAME	R&R	HA01R0		-	
FOR GASOLINE 2WD	R&R	HA01R2		2.0	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
FOR DIESEL 2WD	R&R	HA01R4		2.2	
FRONT STRUT (ONE SIDE)	R&R	HA02R0		1.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
FRONT COIL SPRING (ONE SIDE)	R&R	HA03R0		1.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
STEERING KNUCKLE (ONE SIDE)	R&R	HA04R0		1.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.8	
FRONT SUSPENSION ARM BUSH (ONE SIDE)	R&R	HA05R0		1.0	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.4	
FRONT SUSPENSION ARM (ONE SIDE)	R&R	HA06R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
FRONT STABILIZER BAR AND/OR FRONT STABILIZER BAR MOUNT	R&R	HA08R0		-	
FOR GASOLINE 2WD	R&R	HA08R2		1.8	
FOR DIESEL 2WD	R&R	HA08R4		2.0	
FRONT STABILIZER BAR JOINT (ONE SIDE)	R&R	HA20R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		HA9999		*	
FRONT DRIVE AXLE		HD			
FRONT WHEEL HUB (ONE SIDE)	R&R	HD06R0		1.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.8	
FRONT WHEEL BEARING (ONE SIDE)	R&R	HD07R0		1.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.8	
FRONT WHEEL HUB BOLT (ONE SIDE)	R&R	HD09R0		1.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.9	
WHEEL SIDE BOOT (ONE SIDE)	R&R	HD12R0		1.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
DIFF. SIDE BOOT (ONE SIDE)	R&R	HD13R0		1.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.4	
FRONT DRIVE SHAFT ASSY (RIGHT SIDE)	R&R	HD16R0		0.9	FLAT RATE TIME IS UPDATED
COMBINATION ITEM:					
FRONT DRIVE SHAFT ASSY (LEFT SIDE)	R&R		1	0.2	For Automatic transaxle model
DRIVE INTERMEDIATE SHAFT ASSY	R&R		2	0.1	
RIGHT DIFFERENTIAL SIDE OIL SEAL	R&R		3	0.1	
LEFT DIFFERENTIAL SIDE OIL SEAL	R&R		4	0.1	
FRONT DRIVE SHAFT ASSY (LEFT SIDE)	R&R	HD17R0		0.8	
COMBINATION ITEM:					
LEFT DIFFERENTIAL SIDE OIL SEAL	R&R		1	0.1	
DRIVE INTERMEDIATE SHAFT ASSY	R&R	HD18R0		1.0	For Automatic transaxle model
COMBINATION ITEM:					
RIGHT DIFFERENTIAL SIDE OIL SEAL	R&R		1	0.1	For Automatic transaxle model
DRIVE INTERMEDIATE SHAFT ASSY	OH	HD19H0		1.2	For Automatic transaxle model
COMBINATION ITEM:					
RIGHT DIFFERENTIAL SIDE OIL SEAL	R&R		1	0.1	For Automatic transaxle model
OTHER		HD9999		*	
REAR SUSPENSION (TORSION BEAM TYPE)		HJ			
REAR AXLE	R&R	HJ01R0		2.3	
REAR SHOCK ABSORBER (ONE SIDE)	R&R	HJ04R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.3	
REAR COIL SPRING (ONE SIDE)	R&R	HJ05R0		0.7	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
REAR AXLE BUSHING (ONE SIDE)	R&R	HJ06R0		3.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.8	
OTHER		HJ9999		*	
REAR AXLE SHAFT		HL			
REAR WHEEL HUB BOLT (2WD, DRUM BRAKE, ONE SIDE)	R&R	HL04R0		0.7	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.3	
REAR WHEEL HUB (2WD, DRUM BRAKE, ONE SIDE)	R&R	HL07R0		0.6	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
OTHER		HL9999		*	
TIRE - WHEEL		HP			
WHEEL AND/OR TIRE (INCL. BALANCE: ONE)	R&R	HP01R0		0.5	
COMBINATION ITEM:					
ONE ADDITIONAL	R&R		1	0.3	
TWO ADDITIONAL	R&R		2	0.3	
THREE ADDITIONAL	R&R		3	0.3	
FOUR ADDITIONAL	R&R		4	0.3	
OTHER		HP9999		*	
STEERING WHEEL		LA			
STEERING WHEEL ASSY	R&R	LA01R0		0.4	
HORN PAD AND/OR HORN BUTTON	R&R	LA02R0		0.1	For India Domestic Model
DRIVER AIR BAG MODULE	R&R	LA05R0		0.4	
OTHER		LA9999		*	
STEERING SHAFT		LB			
COLLAPSIBLE STEERING COLUMN ASSY	R&R	LB01R0		1.2	
STEERING COLUMN COVER (ALL)	R&R	LB05R0		0.2	
OTHER		LB9999		*	
STEERING GEAR BOX - LINKAGE (RACK & PINION)		LC			
STEERING TIE ROD END (ONE SIDE)	R&R	LC07R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
STEERING GEAR BOX ASSY	R&R	LC18R0		-	
FOR GASOLINE 2WD	R&R	LC18R2		2.2	
FOR DIESEL 2WD	R&R	LC18R4		2.4	
OTHER		LC9999		*	
BRAKE MASTER CYLINDER		MA			
BRAKE MASTER CYLINDER ASSY	R&R	MA03R0		-	
FOR LHD GASOLINE	R&R	MA03R1		1.1	
FOR RHD GASOLINE	R&R	MA03R3		1.0	
FOR RHD DIESEL	R&R	MA03R4		1.0	
MASTER CYLINDER RESERVOIR AND/OR GROMMET	R&R	MA07R0		-	
FOR LHD GASOLINE	R&R	MA07R1		1.2	
FOR RHD GASOLINE	R&R	MA07R3		1.1	
FOR RHD DIESEL	R&R	MA07R4		1.1	
OTHER		MA9999		*	
BRAKE MASTER BOOSTER		MB			
BRAKE BOOSTER ASSY	R&R	MB01R0		-	
FOR RHD DIESEL	R&R	MB01R2		2.3	
FOR LHD GASOLINE	R&R	MB01R3		1.5	
FOR RHD GASOLINE	R&R	MB01R5		1.7	
BRAKE VACUUM HOSE (BOOSTER SIDE)	R&R	MB04R0		0.3	
FOR DIESEL	R&R	MB04R1		0.3	
BRAKE VACUUM HOSE (ENGINE SIDE)	R&R	MB05R0		-	
FOR DIESEL	R&R	MB05R1		0.2	
OTHER		MB9999		*	
BRAKE PEDAL		MC			
BRAKE PEDAL	R&R	MC05R0		1.1	
FOR RHD	R&R	MC05R1		1.1	
OTHER		MC9999		*	
BRAKE TUBE - HOSE		MD			
FLEXIBLE HOSE (FRONT, ONE SIDE)	R&R	MD01R0		0.9	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
FLEXIBLE HOSE (REAR, ONE SIDE)	R&R	MD02R0		0.9	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
PROPORTIONING VALVE	R&R	MD03R0		0.8	FLAT RATE TIME IS UPDATED
BRAKE PIPE (ONE)	R&R	MD04R0		2.4	
BRAKE PIPE JOINT	R&R	MD05R0		0.9	
ABS ACTUATOR ASSY OR ABS HYDRAULIC UNIT / CONTROL MODULE ASSY	R&R	MD09R0		1.3	
FOR DIESEL	R&R	MD09R1		1.3	
FRONT WHEEL SPEED SENSOR (ONE SIDE)	R&R	MD10R0		0.7	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.2	
REAR WHEEL SPEED SENSOR (ONE SIDE)	R&R	MD11R0		0.7	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.2	
OTHER		MD9999		*	
WHEEL CYLINDER		MG			
REAR WHEEL CYLINDER ASSY (ONE SIDE)	R&R	MG04R0		1.0	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.3	
REAR WHEEL CYLINDER ASSY (ONE SIDE)	OH	MG05H0		1.1	
COMBINATION ITEM: OPPOSITE SIDE	OH		1	0.3	
REAR BRAKE BACKING PLATE (2WD, ONE SIDE)	R&R	MG08R0		1.2	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.3	
OTHER		MG9999		*	
DRUM BRAKE		MH			
REAR BRAKE DRUM (ONE SIDE)	R&R	MH04R0		0.5	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
REAR BRAKE SHOE ASSY (TWO WHEELS)	R&R	MH06R0		0.9	
REAR BRAKE SHOE STRUT ASSY(ONE WHEEL)	R&R	MH07R0		0.7	
COMBINATION ITEM: OPPOSITE WHEEL	R&R		1	0.2	
OTHER		MH9999		*	
DISC BRAKE		MK			
FRONT BRAKE DISC (ONE SIDE)	R&R	MK01R0		0.6	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.2	
FRONT BRAKE CALIPER ASSY (ONE SIDE)	R&R	MK02R0		0.9	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.2	
FRONT BRAKE CALIPER ASSY (ONE SIDE)	OH	MK03H0		1.1	
COMBINATION ITEM: OPPOSITE SIDE	OH		1	0.4	
FRONT DISC BRAKE PAD (BOTH SIDES)	R&R	MK05R0		0.6	
FRONT CALIPER CYLINDER SLIDE BUSHING OR DUST BOOT (ONE SIDE)	R&R	MK06R0		0.5	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
FRONT BRAKE DISC DUST COVER (ONE SIDE)	R&R	MK11R0		1.4	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.8	
OTHER		MK9999		*	
PARKING BRAKE		ML			
PARKING BRAKE LEVER ASSY	R&R	ML01R0		0.4	
PARKING BRAKE CABLE ASSY (ONE OR ONE SIDE)	R&R	ML02R0		0.8	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.3	
OTHER		ML9999		*	
BUMPER		NA			
FRONT BUMPER	R&R	NA01R0		0.8	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
FOR EQUIPPED WITH EXTENSION	R&R	NA01R1		1.0	For India Domestic Model
REAR BUMPER	R&R	NA02R0		0.6	
FOR EQUIPPED WITH EXTENSION	R&R	NA02R2		0.8	For India Domestic Model
COMBINATION ITEM:					
REAR PARKING SENSOR (ALL) AND WIRE	R&R		1	0.1	
FRONT BUMPER EXTENSION	R&R	NA06R0		0.7	
REAR BUMPER EXTENSION	R&R	NA07R0		0.7	
FRONT BUMPER HOLDER (ONE SIDE)	R&R	NA08R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT FOG LAMP BEZEL (ONE SIDE)	R&R	NA10R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR BUMPER HOLDER (ONE SIDE)	R&R	NA11R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR PARKING SENSOR (ALL)	R&R	NA14R0		0.5	
PARKING SENSOR CONTROLLER	R&R	NA15R0		0.7	
PARKING SENSOR BUZZER	R&R	NA20R0		0.7	
REAR REFLECTOR BEZEL (ONE SIDE)	R&R	NA21R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		NA9999		*	
HOOD		NB			
FRONT HOOD PANEL ASSY	R&R	NB01R0		0.4	
FRONT HOOD LOCK	R&R	NB03R0		0.2	
FRONT HOOD LOCK CABLE	R&R	NB04R0		0.8	
FRONT HOOD SILENCER	R&R	NB06R0		0.2	
FRONT HOOD HINGE (ONE SIDE)	R&R	NB08R0		1.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.7	
OTHER		NB9999		*	
FENDER		NC			
FRONT FENDER PANEL (ONE SIDE)	R&R	NC01R0		1.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
FRONT MUD FLAP (ONE SIDE)	R&R	NC03R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR MUD FLAP (ONE SIDE)	R&R	NC04R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT FENDER LINING (ONE SIDE)	R&R	NC06R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR LINING (ONE SIDE)	R&R	NC07R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		NC9999		*	
GRILLE		NG			
RADIATOR UPPER GRILLE	R&R	NG06R0		0.5	
RADIATOR LOWER GRILLE	R&R	NG07R0		0.5	
OTHER		NG9999		*	
EMBLEM - TAPE - MOLDING		NH			
RADIATOR GRILLE EMBLEM	R&R	NH01R0		0.3	
FRONT FENDER EMBLEM (ONE SIDE)	R&R	NH02R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
BACK DOOR EMBLEM OR TRUNK LID EMBLEM (ONE)	R&R	NH03R0		0.2	
ROOF MOLDING (ONE SIDE)	R&R	NH06R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
SIDE SILL SPLASH GUARD OR SILL SIDE CENTER PROTECTOR (ONE SIDE)	R&R	NH18R0		0.3	For India Domestic Model

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.1	For India Domestic Model
COWL CENTER GARNISH	R&R	NH21R0		0.4	
OTHER		NH9999		*	
TRUNK LID		NJ			
TRUNK LID PANEL COMP.	R&R	NJ01R0		0.9	
FOR EQUIPPED WITH REAR SPOILER	R&R	NJ01R1		1.1	For India Domestic Model
TRUNK LID HINGE COMP. (ONE SIDE)	R&R	NJ02R0		1.4	
TRUNK LID HINGE TORSION BAR (ALL)	R&R	NJ03R0		0.3	
TRUNK LID LATCH ASSY	R&R	NJ05R0		0.2	
TRUNK LID LATCH STRIKER	R&R	NJ06R0		0.2	
TRUNK LID OPENING WEATHERSTRIP	R&R	NJ07R0		0.2	
FUEL LID OPENER CABLE COMP.	R&R	NJ10R0		1.0	
FUEL LID OPENER	R&R	NJ11R0		0.3	
FUEL INLET LID	R&R	NJ12R0		0.2	
FUEL LID OPENER LEVER	R&R	NJ13R0		0.7	
REAR SPOILER	R&R	NJ14R0		0.4	
OTHER		NJ9999		*	
WINDSHIELD GLASS		PB			
WINDSHIELD GLASS (ADHERED TYPE)	R&R	PB09R0		2.5	
BACK WINDOW GLASS (ADHERED TYPE)	R&R	PB10R0		3.4	
OTHER		PB9999		*	
DOOR PANEL - TRIM - WEATHERSTRIP		PC			
FRONT DOOR PANEL ASSY (WITHOUT DOOR GLASS, ONE SIDE)	R&R	PC01R0		2.0	
COMBINATION ITEM: FRONT DOOR OUTER TAPE	R&R	1		0.2	
FRONT DOOR OPENING WEATHERSTRIP (ONE SIDE)	R&R	PC03R0		0.3	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.2	
FRONT DOOR UPPER AND/OR LOWER HINGE (ONE SIDE)	R&R	PC04R0		1.4	
FRONT DOOR TRIM (ONE SIDE)	R&R	PC05R0		0.3	
REAR DOOR PANEL ASSY (ONE SIDE)	R&R	PC07R0		2.0	
COMBINATION ITEM: REAR DOOR OUTER TAPE	R&R	1		0.2	
REAR DOOR OPENING WEATHERSTRIP (ONE SIDE)	R&R	PC08R0		0.3	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.2	
REAR DOOR UPPER AND/OR LOWER HINGE (ONE SIDE)	R&R	PC09R0		0.4	
REAR DOOR TRIM (ONE SIDE)	R&R	PC10R0		0.3	
FRONT DOOR OPEN STOP (ONE SIDE)	R&R	PC16R0		0.5	
REAR DOOR OPEN STOP (ONE SIDE)	R&R	PC18R0		0.4	
FRONT DOOR OUTER TAPE (B-PILLAR SIDE)	R&R	PC21R0		1.2	
REAR DOOR OUTER TAPE (B-PILLAR SIDE)	R&R	PC22R0		1.2	
OTHER		PC9999		*	
DOOR GLASS - REGULATOR - LOCK		PD			
FRONT DOOR GLASS (ONE SIDE)	R&R	PD01R0		0.7	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.4	
FRONT DOOR OUTER WEATHERSTRIP (ONE SIDE)	R&R	PD02R0		0.7	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.4	
FRONT DOOR INNER WEATHERSTRIP (ONE SIDE)	R&R	PD03R0		0.3	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.2	
FRONT DOOR GLASS RUN (ONE SIDE)	R&R	PD04R0		0.8	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.5	
FRONT DOOR WINDOW REGULATOR ASSY (ONE SIDE)	R&R	PD05R0		0.8	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.5	
FRONT DOOR OUTSIDE HANDLE ASSY (ONE SIDE)	R&R	PD08R0		0.6	
COMBINATION ITEM: OPPOSITE SIDE	R&R	1		0.3	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
FRONT DOOR LOCK CYLINDER SET (ONE SIDE)	R&R	PD09R0		0.4	
FRONT DOOR LATCH ASSY AND/OR ACTUATOR (ONE SIDE)	R&R	PD10R0		0.7	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.4	
FRONT DOOR INSIDE HANDLE (ONE SIDE)	R&R	PD11R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
FRONT DOOR LATCH STRIKER (ONE SIDE)	R&R	PD12R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR DOOR GLASS (ONE SIDE)	R&R	PD13R0		0.7	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.4	
REAR DOOR OUTER WEATHERSTRIP (ONE SIDE)	R&R	PD17R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
REAR DOOR INNER WEATHERSTRIP (ONE SIDE)	R&R	PD18R0		0.3	FLAT RATE TIME IS UPDATED
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	FLAT RATE TIME IS UPDATED
REAR DOOR GLASS RUN (ONE SIDE)	R&R	PD19R0		0.7	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.4	
REAR DOOR CENTER SASH (ONE SIDE)	R&R	PD20R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
REAR DOOR PARTITION GLASS AND/OR WEATHERSTRIP (ONE SIDE)	R&R	PD21R0		0.5	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.3	
REAR DOOR WINDOW REGULATOR ASSY (ONE SIDE)	R&R	PD22R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
REAR DOOR OUTSIDE HANDLE (ONE SIDE)	R&R	PD25R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
REAR DOOR LATCH ASSY AND/OR ACTUATOR (ONE SIDE)	R&R	PD26R0		0.9	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.6	
REAR DOOR INSIDE HANDLE (ONE SIDE)	R&R	PD27R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
REAR DOOR LATCH STRIKER (ONE SIDE)	R&R	PD29R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT DOOR SASH (ONE SIDE, ONE)	R&R	PD34R0		0.5	
OTHER		PD9999		*	
INSTRUMENT PANEL		QA			
GLOVE BOX	R&R	QA11R0		0.1	
INSTRUMENT CLUSTER PANEL	R&R	QA12R0		0.7	
CAP HOLDER (CENTER POSITION)	R&R	QA13R0		0.1	
INSTRUMENT PANEL CENTER LOWER BOX	R&R	QA19R0		0.4	
INSTRUMENT MAIN UPPER PANEL	R&R	QA22R0		3.4	
INSTRUMENT MAIN LOWER PANEL	R&R	QA23R0		3.7	
OTHER		QA9999		*	
VENTILATOR		QB			
CENTER VENTILATOR LOUVER	R&R	QB01R0		0.8	
SIDE VENTILATOR LOUVER (DRIVER SIDE)	R&R	QB02R0		2.8	
SIDE VENTILATOR LOUVER (PASSENGER SIDE)	R&R	QB03R0		2.8	
CENTER VENTILATOR DUCT	R&R	QB04R0		2.8	
DEFROSTER NOZZLE	R&R	QB07R0		2.7	
REAR LOUVER ASSY	R&R	QB16R0		0.4	
OTHER		QB9999		*	
FRONT SEAT - SEAT BELT		QD			
FRONT SEAT BELT (ONE SIDE)	R&R	QD18R0		0.6	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
COMBINATION ITEM:					
FRONT SEAT BELT BUCKLE	R&R		1	0.2	
FRONT SEAT BELT BUCKLE (ONE SIDE)	R&R	QD19R0		0.3	
FRONT SEAT ASSY (DRIVER SIDE)	R&R	QD30R0		0.4	
COMBINATION ITEM:					
FRONT SEAT ASSY (PASSENGER SIDE)	R&R		1	0.2	
FRONT SEAT ASSY (PASSENGER SIDE)	R&R	QD31R0		0.3	
FRONT SEAT CUSHION TRIM (DRIVER SIDE)	R&R	QD34R0		0.9	
FRONT SEAT CUSHION TRIM (PASSENGER SIDE)	R&R	QD35R0		0.9	
FRONT SEAT CUSHION FRAME (DRIVER SIDE)	R&R	QD40R0		0.7	
FRONT SEAT CUSHION FRAME (PASSENGER SIDE)	R&R	QD41R0		0.7	
FRONT SEAT CUSHION FRAME ASSY (DRIVER SIDE)	R&R	QD42R0		0.9	
FRONT SEAT CUSHION FRAME ASSY (PASSENGER SIDE)	R&R	QD43R0		0.9	
FRONT SEAT BACK TRIM (DRIVER SIDE)	R&R	QD46R0		1.0	
FRONT SEAT BACK TRIM (PASSENGER SIDE)	R&R	QD47R0		1.0	
RECLINING OUTSIDE COVER (DRIVER SIDE)	R&R	QD54R0		0.2	
RECLINING OUTSIDE COVER (PASSENGER SIDE)	R&R	QD56R0		0.2	
FRONT SEAT OUTSIDE ADJUSTER (DRIVER SIDE)	R&R	QD64R0		0.5	
COMBINATION ITEM:					
INSIDE ADJUSTER (DRIVER SIDE)	R&R		1	0.1	
FRONT SEAT INSIDE ADJUSTER (DRIVER SIDE)	R&R	QD65R0		0.5	
FRONT SEAT OUTSIDE ADJUSTER (PASSENGER SIDE)	R&R	QD66R0		0.5	
COMBINATION ITEM:					
INSIDE ADJUSTER (PASSENGER SIDE)	R&R		1	0.1	
FRONT SEAT INSIDE ADJUSTER (PASSENGER SIDE)	R&R	QD67R0		0.5	
FRONT SEAT HEADREST GUIDE (DRIVER SIDE, ALL)	R&R	QD70R0		0.8	
FRONT SEAT HEADREST GUIDE (PASSENGER SIDE, ALL)	R&R	QD71R0		0.8	
FRONT SEAT BACK FRAME ASSY (DRIVER SIDE)	R&R	QD81R0		1.0	
FRONT SEAT BACK FRAME ASSY (PASSENGER SIDE)	R&R	QD82R0		1.0	
OTHER		QD9999		*	
REAR SEAT - SEAT BELT		QE			
REAR SEAT BELT (ONE SIDE)	R&R	QE21R0		0.8	
COMBINATION ITEM:					
REAR SEAT BELT BUCKLE	R&R		1	0.1	
REAR SEAT BELT BUCKLE (ONE SIDE)	R&R	QE22R0		0.2	
REAR SEAT BELT (CENTER POSITION)	R&R	QE23R0		0.2	For India Model
FOR PARTITION PANEL MOUNTING	R&R	QE23R2		0.8	
COMBINATION ITEM:					
REAR SEAT BELT BUCKLE	R&R		1	0.1	
REAR SEAT BELT BUCKLE (CENTER POSITION)	R&R	QE24R0		0.2	
REAR SEAT ARMREST ASSY	R&R	QE25R0		0.4	
REAR SEAT CUSHION ASSY (BENCH TYPE)	R&R	QE30R0		0.1	
REAR SEAT CUSHION TRIM (BENCH TYPE)	R&R	QE32R0		1.3	
REAR SEAT BACK ASSY (BENCH TYPE)	R&R	QE41R0		0.3	
REAR SEAT BACK TRIM (BENCH TYPE)	R&R	QE43R0		1.0	
OTHER		QE9999		*	
FLOOR CARPET - MAT		QG			
FLOOR CARPET	R&R	QG02R0		1.3	
LUGGAGE FLOOR CARPET AND/OR MAT	R&R	QG04R0		0.1	
OTHER		QG9999		*	
INTERIOR TRIM		QH			
FRONT PILLAR TRIM (ONE SIDE)	R&R	QH02R0		0.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
DASH SIDE TRIM (ONE SIDE)	R&R	QH03R0		0.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
CENTER PILLAR UPPER TRIM (ONE SIDE)	R&R	QH04R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
CENTER PILLAR LOWER TRIM (ONE SIDE)	R&R	QH05R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
ROOF LINING	R&R	QH10R0		1.2	
SIDE SILL FRONT SCUFF (ONE SIDE)	R&R	QH11R0		0.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
SIDE SILL REAR SCUFF (ONE SIDE)	R&R	QH12R0		0.1	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR PILLAR TRIM (ONE SIDE)	R&R	QH13R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
PARTITION TRIM	R&R	QH14R0		0.7	
TRUNK ROOM SIDE TRIM (ONE SIDE)	R&R	QH16R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
TAIL END MEMBER TRIM	R&R	QH17R0		0.1	
ASSISTANT GRIP (ONE)	R&R	QH18R0		0.2	
COMBINATION ITEM:					
ONE ADDITIONAL	R&R		1	0.1	
TWO ADDITIONAL	R&R		2	0.1	
THREE ADDITIONAL	R&R		3	0.1	
FRONT DOOR OPENING TRIM (ONE SIDE)	R&R	QH19R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR DOOR OPENING TRIM (ONE SIDE)	R&R	QH20R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		QH9999		*	
CONSOLE - MIRROR - SUN VISOR		QJ			
CONSOLE BOX ASSY	R&R	QJ01R0		0.2	
REMOTE CONTROLLED MIRROR ASSY (ONE SIDE)	R&R	QJ03R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.2	
INSIDE MIRROR ASSY	R&R	QJ04R0		0.2	
REAR VIEW MIRROR COVER (ONE SIDE)	R&R	QJ07R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR VIEW MIRROR GLASS (ONE SIDE)	R&R	QJ08R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OVER HEAD BOX ASSY	R&R	QJ09R0		0.2	
SUN VISOR ASSY (ONE SIDE)	R&R	QJ12R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		QJ9999		*	
HEADLAMP - TURN SIGNAL LAMP		SA			
HEADLAMP UNIT OR HEADLAMP ASSY (ONE SIDE)	R&R	SA02R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.3	
FRONT TURN SIGNAL LAMP LENS AND/OR BULB (ONE SIDE)	R&R	SA06R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
SIDE TURN SIGNAL LAMP ASSY (ONE SIDE)	R&R	SA10R0		-	
FOR REAR VIEW MIRROR TYPE	R&R	SA10R1		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT FOG LAMP UNIT OR FRONT FOG LAMP ASSY (ONE)	R&R	SA14R0		0.6	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT FOG LAMP BULB (ONE SIDE)	R&R	SA15R0		0.4	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
CLEARANCE LAMP LENS AND/OR BULB (ONE SIDE)	R&R	SA17R0		0.2	
COMBINATION ITEM:					

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
OPPOSITE SIDE	R&R		1	0.1	
HEADLAMP BULB (HALOGEN, ONE SIDE)	R&R	SA30R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
OTHER		SA9999		*	
TAIL LAMP		SB			
REAR COMBINATION LAMP ASSY (ONE SIDE)	R&R	SB02R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR COMBINATION LAMP BULB (ONE SIDE)	R&R	SB05R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
HIGH MOUNT STOP LAMP ASSY	R&R	SB08R0		0.2	
FOR REAR SPOILER	R&R	SB08R2		0.4	For India Domestic Model
LICENSE LAMP ASSY (ONE)	R&R	SB10R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
LICENSE LAMP GARNISH OR LICENSE LAMP COVER	R&R	SB12R0		0.4	
BACK UP LAMP ASSY (ONE SIDE)	R&R	SB14R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
BACK UP LAMP BULB (ONE SIDE)	R&R	SB16R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
REAR REFLECTOR ASSY (ONE SIDE)	R&R	SB22R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
LICENSE LAMP BULB (ALL)	R&R	SB25R0		0.3	
OTHER		SB9999		*	
INTERIOR LAMP		SC			
ROOM LAMP ASSY	R&R	SC01R0		0.2	
ROOM LAMP LENS AND/OR BULB	R&R	SC02R0		0.2	
SPOT LAMP ASSY	R&R	SC05R0		0.2	
SPOT LAMP BULB	R&R	SC06R0		0.2	
CENTER ROOM LAMP ASSY (ONE OR ONE SIDE)	R&R	SC11R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
CENTER ROOM LAMP LENS AND/OR BULB (ONE OR ONE SIDE)	R&R	SC12R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
TRUNK ROOM LAMP ASSY	R&R	SC15R0		0.2	
TRUNK ROOM LAMP LENS AND/OR BULB	R&R	SC16R0		0.2	
OTHER		SC9999		*	
WIRING HARNESS		SD			
WIRING NO.2 OR INSTRUMENT PANEL HARNESS	R&R	SD04R0		3.2	
WIRING NO.3 OR FLOOR WIRING HARNESS	R&R	SD05R0		4.4	
WIRING NO.5 OR ENGINE WIRING HARNESS	R&R	SD07R0		1.5	
FOR DIESEL	R&R	SD07R4		1.1	
MAIN WIRING HARNESS	R&R	SD24R0		5.4	
FOR DIESEL	R&R	SD24R2		9.1	
TRUNK ROOM HARNESS ASSY	R&R	SD25R0		0.5	
FUEL HARNESS	R&R	SD37R0		1.2	FLAT RATE TIME IS UPDATED
REAR COMBINATION LAMP SOCKET & CORD ASSY (ONE SIDE)	R&R	SD42R0		0.3	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
FRONT DOOR HARNESS (ONE SIDE)	R&R	SD43R0		1.0	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.6	
REAR DOOR HARNESS (ONE SIDE)	R&R	SD44R0		0.8	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.5	
ENGINE WIRING HARNESS (SECOND)	R&R	SD45R0		-	
FOR DIESEL	R&R	SD45R1		1.8	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
REAR PARKING SENSOR WIRE	R&R	SD47R0		0.5	
GLOW CONTROL WIRE	R&R	SD49R0		0.6	
ROOF WIRE	R&R	SD50R0		3.6	
OTHER		SD9999		*	
METER		SE			
SPEEDOMETER ASSY	R&R	SE01R0		0.8	
METER WINDOW GLASS	R&R	SE35R0		0.7	
OTHER		SE9999		*	
WINDSHIELD WIPER		SG			
FRONT WIPER ARM ASSY (BOTH SIDES)	R&R	SG01R0		0.2	
FRONT WIPER BLADE ASSY (BOTH SIDES)	R&R	SG03R0		0.1	
FRONT WIPER MOTOR ASSY	R&R	SG05R0		0.4	
OTHER		SG9999		*	
WINDSHIELD WASHER		SH			
FRONT WASHER TANK	R&R	SH01R0		0.6	
FRONT WASHER PUMP ASSY	R&R	SH03R0		0.6	
FRONT WASHER NOZZLE (BOTH SIDES)	R&R	SH05R0		0.3	
OTHER		SH9999		*	
HORN		SJ			
HIGH PITCHED HORN ASSY	R&R	SJ04R0		0.4	
COMBINATION ITEM: LOW PITCHED HORN ASSY	R&R		1	0.1	
LOW PITCHED HORN ASSY	R&R	SJ05R0		0.4	
OTHER		SJ9999		*	
CAR AUDIO		SK			
TUNER ASSY	R&R	SK02R0		0.4	
REAR CAMERA ASSY	R&R	SK14R0		0.2	
TWEETER SPEAKER ASSY (ONE SIDE)	R&R	SK15R0		0.2	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
FRONT SPEAKER ASSY (ONE SIDE)	R&R	SK18R0		0.4	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
REAR SPEAKER ASSY (ONE SIDE)	R&R	SK19R0		0.3	
COMBINATION ITEM: OPPOSITE SIDE	R&R		1	0.1	
GPS ANTENNA	R&R	SK20R0		0.7	
USB CABLE	R&R	SK21R0		0.8	
USB SOCKET	R&R	SK22R0		0.5	
MICROPHONE	R&R	SK23R0		0.2	
RADIO ANTENNA AMPLIFIER	R&R	SK30R0		0.5	
OTHER		SK9999		*	
SWITCHES		SM			
IGNITION SWITCH ASSY	R&R	SM01R0		0.4	
FOR PUSH START TYPE	R&R	SM01R1		0.4	
STEERING LOCK ASSY	R&R	SM02R0		1.2	
LOCK SET	R&R	SM03R0		1.3	
LIGHTING SWITCH ASSY AND/OR TURN SIGNAL SWITCH ASSY	R&R	SM04R0		0.3	
FRONT FOG LAMP SWITCH ASSY	R&R	SM05R0		0.3	
FRONT WIPER/WASHER SWITCH ASSY	R&R	SM07R0		0.3	
COMBINATION SWITCH ASSY OR CONTACT COIL ASSY	R&R	SM11R0		0.6	
CLUTCH PEDAL POSITION SWITCH ASSY	R&R	SM12R0		1.1	
BACK DOOR REQUEST SWITCH OR BACK DOOR (OPENER) SWITCH ASSY OR TRUNK LID REQUEST SWITCH OR TRUNK LID (OPENER) SWITCH ASSY	R&R	SM13R0		0.3	
DOOR SWITCH ASSY (ONE)	R&R	SM14R0		0.2	
COMBINATION ITEM: ONE ADDITIONAL	R&R		1	0.1	
TWO ADDITIONAL	R&R		2	0.1	
THREE ADDITIONAL	R&R		3	0.1	
STOP LAMP SWITCH ASSY OR AT LOCK UP SWITCH ASSY	R&R	SM15R0		0.3	
MIRROR CONTROL SWITCH ASSY	R&R	SM21R0		0.4	
TRUNK LID UNLATCH SWITCH OR TRUNK SWITCH ASSY	R&R	SM27R0		0.2	
FRONT POWER WINDOW MAIN SWITCH ASSY	R&R	SM28R0		0.4	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
COMBINATION ITEM:					
FRONT POWER WINDOW SUB SWITCH ASSY	R&R		1	0.1	
FRONT POWER WINDOW SUB SWITCH ASSY	R&R	SM29R0		0.2	
REAR POWER WINDOW SUB SWITCH ASSY (ONE SIDE)	R&R	SM30R0		0.2	
COMBINATION ITEM:					
OPPOSITE SIDE	R&R		1	0.1	
KEYLESS TRANSMITTER ASSY OR KEYLESS START REMOTE CONTROL LFR ASSY	R&R	SM33R0		-	
FOR EQUIPPED WITH IMMOBILIZER	R&R	SM33R1		0.4	
BODY CONTROL MODULE (BCM)	R&R	SM34R0		0.8	
HEADLAMP LEVELING SWITCH	R&R	SM35R0		0.3	
HAZARD WARNING SWITCH	R&R	SM45R0		0.8	
CLUTCH PEDAL POSITION NO.2 SWITCH ASSY	R&R	SM53R0		0.3	
CANCEL CAM AND HORN BODY	R&R	SM54R0		0.6	For India Domestic Model
OTHER		SM9999		*	
RELAY - CONTROLLER		SN			
TRANSMISSION CONTROL MODULE (TCM)	R&R	SN10R0		0.7	For Automatic transaxle model
CIGARETTE LIGHTER ASSY OR ACCESSARY SOCKET BODY	R&R	SN11R0		0.4	
AIR BAG SENSING/DIAGNOSTIC MODULE ASSY	R&R	SN33R0		0.5	
AIR BAG FORWARD SENSOR ASSY (ALL)	R&R	SN34R0		0.8	
PASSENGER AIR BAG MODULE	R&R	SN35R0		3.3	
IMMOBILIZER CONTROL MODULE ASSY	R&R	SN46R0		0.6	
ELECTRICAL POWER STEERING CONTROLLER	R&R	SN48R0		1.0	
KEYLESS START (DOOR OPENER) CONTROLLER ASSY	R&R	SN61R0		0.6	FLAT RATE TIME IS UPDATED
RELAY (RELAY BOX)	R&R	SN94R0		0.3	
RELAY (JUNCTION BOX)	R&R	SN96R0		0.7	FLAT RATE TIME IS UPDATED
OTHER		SN9999		*	
SWITCHES - CONTROLLER		ST			
KEYLESS START SYSTEM ANTENNA (BACK PANEL)	R&R	ST07R0		0.7	
KEYLESS START SYSTEM ANTENNA (CONSOLE BOX)	R&R	ST09R0		0.4	
KEYLESS START SYSTEM ANTENNA (PARTITION PANEL)	R&R	ST11R0		0.4	
OTHER		ST9999		*	
HEATER		TA			
HEATER ASSY	R&R	TA01R0		4.3	
HEATER CORE OR HEATER UNIT	R&R	TA03R0		4.4	
BLOWER RESISTER OR DRIVER FAN	R&R	TA04R0		0.4	
HEATER CONTROL LEVER ASSY	R&R	TA06R0		0.7	
HEATER CONTROL CABLE (ALL)	R&R	TA07R0		0.7	
HEATER BLOWER MOTOR UNIT	R&R	TA08R0		0.3	
COMBINATION ITEM:					
BLOWER RESISTER OR DRIVER FAN	R&R		1	0.1	
TEMPERATURE CONTROL ACTUATOR (ONE OR ONE SIDE)	R&R	TA10R0		0.7	
FOR RHD	R&R	TA10R1		4.6	
AIR FLOW CONTROL ACTUATOR	R&R	TA11R0		1.2	
FOR RHD	R&R	TA11R1		0.7	FLAT RATE TIME IS UPDATED
AIR INTAKE CONTROL ACTUATOR	R&R	TA12R0		0.7	
FOR RHD	R&R	TA12R1		0.7	FLAT RATE TIME IS UPDATED
AIR FILTER	R&R	TA16R0		0.2	
AIR INTAKE CASE ASSY	R&R	TA17R0		4.5	
FOR RHD	R&R	TA17R1		4.5	
OTHER		TA9999		*	
AIR CONDITIONER		TB			
V-BELT OR A/C BELT	R&R	TB01R0		0.6	For Gasoline model
COMPRESSOR ASSY	R&R	TB02R0		1.6	
FOR DIESEL	R&R	TB02R1		1.6	
MAGNET CLUTCH ASSY	R&R	TB04R0		1.9	
FOR DIESEL	R&R	TB04R1		1.8	
CONDENSER ASSY	R&R	TB06R0		1.6	
FOR DIESEL	R&R	TB06R1		1.8	
EVAPORATOR UNIT	R&R	TB09R0		4.6	
EXPANSION VALVE	R&R	TB10R0		1.5	
THERMOSTAT OR THERMISTOR	R&R	TB14R0		4.6	
AUTO A/C PANEL UNIT	R&R	TB25R0		0.5	
AUTO A/C CONTROLLER UNIT	R&R	TB26R0		0.6	

OPERATION		OPERATION NUMBER		FLAT RATE TIME	REMARKS
		BASIC CODE	V/C CODE		
DRYER KIT	R&R	TB28R0		1.5	
A/C REFRIGERANT PRESSURE SENSOR	R&R	TB29R0		1.2	
OUTSIDE AIR TEMPERATURE SENSOR	R&R	TB30R0		0.5	
INSIDE AIR TEMPERATURE SENSOR	R&R	TB31R0		0.7	
DISCHARGE HOSE	R&R	TB32R0		1.4	
LIQUID PIPE SET	R&R	TB33R0		2.0	FLAT RATE TIME IS UPDATED
FOR DIESEL	R&R	TB33R1		2.7	
SUCTION HOSE	R&R	TB34R0		1.3	
SUN LIGHT SENSOR	R&R	TB43R0		0.3	
SUCTION PIPE OR SUCTION PIPE NO.1	R&R	TB47R0		1.4	
OTHER		TB9999		*	