























- J 1 Junction Connector
- N 1 Neutral Start SW
- P 1 Pressure SW
- S 2 Skid Control ECU with Actuator
- S 3 Speed Sensor
- S 4 Speed Sensor (Front LH)
- S 5 Speed Sensor (Front RH)
- S 6 Starter
- S 7 Starter (1KD-FTV, 2KD-FTV)
- S 8 Suction Control Valve
- S 9 Swirl Control Valve
- T 1 Throttle Body Assembly
- T 2 Throttle Body Assembly
- T 3 Transfer Indicator SW (4WD Position) (Except 1GR-FE)
- T 4 Transfer Indicator SW (L4 Position)
- T 5 Transfer Indicator SW (Neutral Position)
- T 6 Transmission Revolution Sensor (Input)
- T 7 Transmission Revolution Sensor (Output)
- T 9 Turbo Pressure Sensor
- T 10 Turbocharger Variable Nozzle Motor
- T 11 Turbocharger Variable Nozzle Sensor
- T 12 Turn Signal Lamp (Front LH)
- T 13 Turn Signal Lamp (Front RH)
- T 14 Turn Signal Lamp (Front Side LH)
- T 15 Turn Signal Lamp (Front Side RH)
- V 1 VRV (EGR)
- V 2 VSV (EGR Cut Valve)
- W 1 Water Temp. Sensor
- W 2 Windshield Washer Motor
- W 3 Windshield Wiper Motor




T 12

Gray



T 13

Gray



T 14

Gray



T 15

Gray




V 1

Black



V 2

Brown




W 1

Black



W 2

Black



W 3

Black

