


Last Modified: 3-27-2012	6.4 K	From: 201203
Model Year: 2013	Model: FR-S	Doc ID: RM000004I1L003X
Title: MIRROR (INT): INNER REAR VIEW MIRROR: COMPONENTS (2013 FR-S)		

COMPONENTS


ILLUSTRATION



Last Modified: 3-27-2012	6.4 A	From: 201203
Model Year: 2013	Model: FR-S	Doc ID: RM000004I1K003X
Title: MIRROR (INT): INNER REAR VIEW MIRROR: INSTALLATION (2013 FR-S)		

INSTALLATION

1. INSTALL INNER REAR VIEW MIRROR SPRING PIN




(a) Install the new inner rear view mirror spring pin to the mirror base in the order as shown in the illustration.

Text in illustration

*1	Mirror base
----	-------------

2. INSTALL INNER REAR VIEW MIRROR ASSEMBLY



(a) Slide and install the inner rear view mirror as shown in the illustration.

(b) Turn the inner rear view mirror assembly in the direction indicated by the arrow in the illustration.

HINT:


Turning direction can be either right or left.



Last Modified: 3-27-2012	6.4 A	From: 201203
Model Year: 2013	Model: FR-S	Doc ID: RM000004I1M003X
Title: MIRROR (INT): INNER REAR VIEW MIRROR: REMOVAL (2013 FR-S)		

REMOVAL

1. REMOVE INNER REAR VIEW MIRROR ASSEMBLY




(a) Turn the inner rear view mirror assembly in the direction indicated by the arrow in the illustration.

HINT:
Turning direction can be either right or left.

(b) Slide the inner rear view mirror assembly forward and remove it.

2. REMOVE INNER REAR VIEW MIRROR SPRING PIN



(a) Remove the inner rear view mirror spring pin from mirror base in the order as shown in the illustration.

Text in illustration

*1	Mirror base
----	-------------

