



CRUISE CONTROL MAIN SWITCH REPLACEMENT

8202R-02

1. DISCONNECT BATTERY NEGATIVE TERMINAL (See page 60-1)
2. REMOVE STEERING WHEEL COVER LOWER NO.2
3. REMOVE STEERING WHEEL COVER LOWER NO.3
4. REMOVE HORN BUTTON ASSY (See page 60-15)



5. REMOVE CRUISE CONTROL MAIN SWITCH
 - (a) Disconnect the connector.
 - (b) Remove the 2 screws and cruise control main switch.



6. INSTALL HORN BUTTON ASSY (See page 60-15)
7. INSPECT HORN BUTTON ASSY (See page 60-10)
8. INSPECT SRS WARNING LIGHT (See page 05-1238)