


Vauxhall Zafira C Tourer 2014 – 2015 fuse box diagram

Engine compartment fuse box



Vauxhall Zafira C Tourer – fuse box – engine

compartment

The fuse box is in the front left of the engine compartment.

Disengage the cover and fold it upwards until it stops. Remove the cover vertically upwards.

Number	Circuit
1	Engine control module
2	Lambda sensor
3	Fuel injection, ignition system
4	Fuel injection, ignition system
5	—


6	Mirror heating, anti-theft alarm system
7	Fan control, engine control module, transmission control module
8	Lambda sensor, engine cooling
9	Rear window sensor
10	Battery sensor
11	Trunk release
12	Adaptive forward lighting, auto- matic light control
13	ABS
14	Rear window wiper
15	Engine control module
16	Starter
17	Transmission control module
18	Heated rear window
19	Front power windows
20	Rear power windows

21	Tylna centralka elektryczna
22	Left high beam (Halogen)
23	Headlamp washer system
24	Right low beam (Xenon)
25	Left low beam (Xenon)
26	Front fog lights
27	Diesel fuel heating
28	Stop-start system
29	Electric parking brake
30	ABS
31	Adaptive cruise control
32	Airbag
33	Adaptive forward lighting, auto- matic light control
34	Exhaust gas recirculation
35	Outside rear view mirror, rain sensor

36	Climate control
37	Canister vent solenoid
38	Vacuum pump
39	Central control module
40	Windscreen washer, rear window washer system
41	Right high beam (Halogen)
42	Radiator fan
43	Windscreen wiper
44	Windscreen wiper
45	Radiator fan
46	—
47	Horn
48	Radiator fan
49	Fuel pump
50	Headlamp levelling, adaptive forward lighting

51	Air shutter
52	Auxiliary heater, diesel engine
53	Transmission control module, engine control module
54	Vacuum pump, instrument panel cluster, heating ventilation, air conditioning system

Instrument panel fuse box



Vauxhall Zafira C Tourer – fuse box – instrument panel

In left-hand drive vehicles, the fuse box is behind the storage compartment in the instrument panel.

Open the compartment and push it to the left to unlock. Fold the compartment down and remove it.

In right-hand drive vehicles, the fuse box is located behind a cover in the glovebox.


Open the glovebox, then open the cover and fold it down.

Number	Circuit
1	Cruise control, speed limiter, adaptive cruise control, steering wheel controls
2	Exterior lights, body control module
3	Exterior lights, body control module

4	Infotainment system
5	Infotainment system, instrument
6	Power outlet, cigarette lighter
7	Power outlet
8	Left low beam, body control module
9	Right low beam, body control module, airbag module
10	Door locks, body control module
11	Interior fan
12	—
13	—
14	Diagnostic connector
15	Airbag
16	Power outlet
17	Air conditioning system
18	Logistics

19	Body control module
20	Body control module
21	Instrument panel cluster, antitheft alarm system
22	Ignition sensor
23	Body control module
24	Body control module
25	—
26	—

Load compartment fuse box



Vauxhall Zafira C Tourer – fuse box – load compartment

The fuse box is on the left side of the load compartment behind a cover.

If equipped with tyre repair kit, remove the complete box.

Number	Circuit

1	—
2	Trailer outlet
3	Parking assist
4	Selective catalytic reduction system
5	—
6	—
7	Power seat
8	—
9	Selective catalytic reduction system
10	Nitrogen oxide sensor
11	Trailer module, trailer socket
12	Trailer module
13	Trailer outlet
14	—
15	—

16	Inside mirror, rear view camera
17	Power outlet
18	—
19	Steering wheel heating
20	Sunblind
21	Heated front seats
22	—
23	—
24	Selective catalytic reduction system
25	—
26	—
27	—
28	—
29	—
30	—

31	—
32	Active damping system, lane departure warning