

Index

Articulated lever

- assembly 58.5

Door handle

- assembly 58.3


Door lock

- assembly 58.2

Pull rod


- adjusting 58.4

Body — Rear Doors




58-27

Body – Rear Doors




58-272



► Fig. 1 Pull rod, adjusting

- adjust screw so there is no slack or pre-tension in pull rod
- hook pull rod 2 into adjusting screw 1 and lock part 3

Body – Rear Doors



58-275