

Oldsmobile Alero 2003-2004

Remote Starter Wiring Colors and Notes

Function	Vehicle Color	Location
Start:	Yellow (+)*	Ignition switch harness*
Ignition #1:	Pink (+)	Ignition switch harness
Ignition #2:	Dk.Green (+)	Ignition switch harness
Ignition #3:	N/A	Ignition switch harness
Accessory:	Orange (+)	Ignition switch harness
Brake Light:	Lt.Blue (+)	Brake pedal switch
Tach Signal:	White or PURPLE / White (AC)	At the PCM**
Parking Lights:	Brown (+)	Gray plug at the BCM***
Headlights:	N/A	
Diesel Glow Plug:	N/A	
Clutch Bypass Wire:	N/A	
Notes:	*This vehicle is equipped with GM's Passlock II Anti-Theft Security System. Use Universal Alarm Bypass Module part #2x402 where X can be any number.**On the 2.2L models use white wire in the black plug. On the 3.4L models use PURPLE / white in the blue plug. The Powertrain Control Module (PCM) is under the driver side dash left of the steering column. ***The Body Control Module (BCM) is between the blower motor and the passenger side kick panel.	

Oldsmobile Alero 2003-2004

Alarm and Keyless Entry Wiring Colors and Notes

Function	Vehicle Color	Location
Constant +12 Volts:	Red & RED / Black (+)	Ignition switch harness
OEM Alarm Disarm:	N/A	
Dome Lights/Superv:	White (-)	Pink plug at BCM***
OEM Horn:	Black (-)	Gray plug at BCM***

Power Lock:	White (-)	Gray plug at BCM***
Power Unlock:	Same wire as power lock	Gray plug at BCM***
Trunk Release:	Black (-)	Gray plug at BCM***
Alarm Input Wire:	White (-)	Pink plug at BCM***

Notes: ***The Body Control Module (BCM) is between the blower motor and the passenger side kick panel.