



F RELAY LOCATIONS

[Engine Compartment]




[Instrument Panel]

*1:w/ Theft Deterrent System,w/ Door Lock Control
 *2:w/ Theft Deterrent System,w/o Door Lock Control
 *3:w/o Theft Deterrent System,w/ Door Lock Control




F RELAY LOCATIONS

 : Driver Side J/B	Left Kick Panel (See Page 19)
--	-------------------------------




[Driver Side J/B Inner Circuit]



F RELAY LOCATIONS

② : Engine Room R/B	Engine Compartment Left (See Page 18)
---------------------	---------------------------------------



⑤ : Engine Room R/B No.5

Engine Compartment Left (See Page 18)

(Canada)

