


2011 MURANO

QUICK REFERENCE GUIDE





- | | | | |
|--|--|---|---|
| 01 INSTRUMENT BRIGHTNESS CONTROL* | 07 STEERING WHEEL SWITCHES FOR AUDIO / BLUETOOTH* | 13 VEHICLE DYNAMIC CONTROL (VDC) OFF SWITCH* | 19 PUSH BUTTON IGNITION SWITCH |
| 02 TWIN TRIP ODOMETER SWITCHES* | 08 CRUISE CONTROL | 14 ALL-WHEEL DRIVE (AWD) LOCK SWITCH* | 20 AUDIO SYSTEM |
| 03 HEADLIGHT AND TURN SIGNAL CONTROL | 09 HEATED STEERING WHEEL SWITCH* | 15 REMOTE WALK-IN SWITCH | 21 AUTOMATIC CLIMATE CONTROLS |
| 04 LOW TIRE PRESSURE WARNING LIGHT | 10 TRUNK LID RELEASE SWITCH | 16 TILT / TELESCOPIC STEERING COLUMN* | 22 FRONT PASSENGER AIR BAG STATUS LIGHT* |
| 05 DOT MATRIX LIQUID CRYSTAL DISPLAY* | 11 FUEL-FILLER DOOR RELEASE SWITCH | 17 HOOD RELEASE* | 23 SOFT TOP OPENER SWITCH |
| 06 WINDSHIELD WIPER / WASHER SWITCH | 12 INTELLIGENT KEY™ PORT* | 18 CONTROL PANEL DISPLAY* | |

*See your Owner's Manual for more information.

NEW SYSTEM FEATURES

Heated Steering Wheel (if so equipped)	2
Opening the Soft Top (CrossCabriolet models)	2

ESSENTIAL INFORMATION

Loose Fuel Cap	3
Tire Pressure Monitoring System (TPMS)	3
Automatic Power Windows (CrossCabriolet models)	4
Before Operating the Soft Top (CrossCabriolet models)	4

FIRST DRIVE FEATURES

NISSAN Intelligent Key™ System	5
Power Seat Adjustments (if so equipped)	5
Rear Seat Entry/Exit (CrossCabriolet models)	6
Outside Mirror Control Switch	7
Starting/Stopping the Engine	7
Headlight Control Switch	7
Windshield Wiper Switch	8
Automatic Climate Controls	8
FM/AM/XM® Radio with CD/DVD Player (if so equipped)	9
Parking Brake	9
Soft Top Operation (CrossCabriolet models)	10
Trunk Lid Release (CrossCabriolet models)	10
Power Liftgate Release (Hardtop models—if so equipped)	11
Fuel-Filler Door	11

SYSTEM GUIDE

Cruise Control	12
Bluetooth® Hands-free Phone System (if so equipped)	12
Navigation System (if so equipped)	12
DVD Entertainment System (if so equipped)	13
HomeLink® Universal Transceiver (if so equipped)	13



- Always wear your seat belt.
- Supplemental air bags do not replace proper seat belt usage.
- Children 12 and under should always ride in the rear seat properly secured in child restraints or seat belts according to their age and weight.
- Do not drink and drive.

For more information, refer to the **“Safety — Seats, seat belts and supplemental restraint system (section 1)”** of your Owner’s Manual.



Additional information about your vehicle is also available in your Owner’s Manual, Navigation System Owner’s Manual, Electronic Quick Reference Guide (EQRG) and at www.nissanusa.com.




This easy-to-use Quick Reference Guide is intended to help you more fully appreciate some of the unique features and functions of your new vehicle. However, it is not intended to replace your Owner’s Manual. The Owner’s Manual contains more detailed information to help you better understand the important safety warnings, features, operation and maintenance of your vehicle. All information, specifications, photographs and illustrations in this publication are those in effect at the time of printing. NISSAN reserves the right to change specifications or design without notice and without obligation.

new system features

HEATED STEERING WHEEL (if so equipped)

- Once activated, your heated steering wheel will automatically turn on and off to maintain a temperature above 68 degrees Fahrenheit.
- When the surface temperature of the steering wheel is above 68°F (20°C) and the switch is turned on, the system will not heat the steering wheel. This does not indicate a malfunction.

For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.




OPENING THE SOFT TOP (CrossCabriolet models)

- The soft top can be opened from outside the vehicle using the door handle request switch **01** as follows:
 - The luggage cover must be pulled out and hung on both hooks.
 - The ignition switch must be in the **OFF** position.
 - Push and hold the door handle request switch **01** until the soft top is fully opened.

NOTE: It is important to make sure the NISSAN Intelligent Key™ is with you (that is, in your pocket or purse).


For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



LOOSE FUEL CAP

- A LOOSE FUEL CAP warning message will appear in the dot matrix liquid crystal display **01** when the fuel-filler cap is not tightened correctly.
- The warning message will disappear when the vehicle detects the fuel-filler cap is properly tightened and the reset button **02** is pressed.
- If the cap is not properly tightened the Malfunction Indicator Light  may illuminate.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



TIRE PRESSURE MONITORING SYSTEM (TPMS)

- A CHECK TIRE PRESSURE warning message will appear in the dot matrix liquid crystal display **01** and the TPMS light will illuminate when one or more tires are low on pressure and air is needed.
- After tire pressures are adjusted, drive the vehicle at speeds above 16 MPH (25km/h) and the warning and indicator light will disappear.
- When the low tire pressure warning light flashes for approximately 1 minute and then remains on, the TPMS is not functioning properly. Have the system checked by a NISSAN dealer.
- Tire pressure rises and falls depending on the heat caused by the vehicle’s operation and the outside temperature. Low outside temperature can lower the temperature of the air inside the tire, which can cause a lower tire inflation pressure. This may cause the low tire pressure warning light to illuminate. If the warning light illuminates in low ambient temperature, check the tire pressure in all four tires.




For more information, refer to the “**Instruments and controls (section 2)**” and the “**Starting and driving (section 5)**” of your Owner’s Manual.

essential information

AUTOMATIC POWER WINDOWS (CrossCabriolet models)

- Your power windows have an automatic adjusting function to ensure windows close completely to help seal against wind noise and weather leaks.
- When the front doors are opened, the windows automatically lower slightly to avoid contact between the windows and the side roof panels.
- If your vehicle's battery has been discharged or disconnected, the power window automatic adjusting function will not operate.
- Refer to your Owner's Manual for information on how to initialize your power window system.
- If the power window functions do not operate properly after initializing the system, have your vehicle checked by a NISSAN dealer.




For more information, refer to the **"Instruments and controls (section 2)"** of your Owner's Manual.

BEFORE OPERATING THE SOFT TOP (CrossCabriolet models)

- Do not place anything in the top storage area. Cargo that contacts the top could damage the top and/or the vehicle body. See Caution label **01** in the trunk.
- Do not place anything on the soft top, rear parcel shelf, inner flaps, storage lid or trunk lid. Even small items may interfere with the top operation and could cause damage to the top or the vehicle body.

For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.



NISSAN INTELLIGENT KEY™ SYSTEM

The NISSAN Intelligent Key™ System allows you to lock or unlock your vehicle, open your liftgate/trunk lid and start the engine.

- To lock or unlock the driver's or front passenger's door, push the door handle request switch **01** once.
- Push the door handle request switch **01** within 1 minute of unlocking the door and all other doors will unlock.

NOTE: It is important to make sure the Intelligent Key is with you (that is, in your pocket or purse).

For more information, refer to the **"Pre-driving checks and adjustments (section 3)"** of your Owner's Manual.




POWER SEAT ADJUSTMENTS (if so equipped)

- Push the control switch **01** forward or backward to slide the seat forward or backward.
- Push the switch **02** forward or backward to adjust the angle of the seatback.

SEAT LIFTER (if so equipped for driver's seat)

- To adjust the angle and height of the seat cushion, push the front or rear end of the switch **01** up or down.



LUMBAR SUPPORT (if so equipped for driver's seat)

- To adjust the seat lumbar area, push the front or back portion of the switch **03**.

For more information, refer to the **"Safety — Seats, seat belts and supplemental restraint system (section 1)"** of your Owner's Manual.

first drive features

REAR SEAT ENTRY/EXIT (CrossCabriolet models)

DRIVER'S SIDE

- To enter the rear seat, push and hold the front end of the slide switch **01** to slide the driver's seat forward.
- Then push and hold the front end of the reclining switch **02** until the desired angle is obtained.
- To exit the rear seat from the driver's side, pull the strap **03** behind the driver's seat to release the driver's seatback. The driver's seatback will tilt forward so that you can exit the vehicle.



PASSENGER'S SIDE

- Push the front passenger's seatback switch **04** to fold down the front passenger's seatback and unlock the seat position.
- Manually slide the seat forward to the foremost position.
- Enter or exit the back seat.
- To slide the front passenger's seat back into position, push the bottom half of the seatback **05** until it locks. Next, adjust the seatback by pulling the seatback lever **06** up. Release the lever to lock the seatback into position.



For more information, refer to the “**Safety – Seats, seat belts and supplemental restraint system (section 1)**” of your Owner's Manual.

OUTSIDE MIRROR CONTROL SWITCH

- Turn the control switch right or left to select the right or left side mirror.
- Move the control switch up, down, right or left to adjust the mirror angle.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



STARTING/STOPPING THE ENGINE

- Depress the brake pedal.
- Press the ignition switch **START/STOP** button to start the engine.

NOTE: It is important to make sure the NISSAN Intelligent Key™ is with you (that is, in your pocket or purse).

TURNING THE ENGINE OFF

- Move the shift lever to the P (PARK) position and apply the parking brake.
- Press the ignition switch **START/STOP** button to turn the engine off.



EMERGENCY ENGINE SHUT OFF

To shut off the engine in an emergency situation while driving, perform one of the following procedures:


- Rapidly push the push button ignition switch 3 consecutive times, or
- Push and hold the push button ignition switch for more than 2 seconds.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.

HEADLIGHT CONTROL SWITCH

- Turn the headlight control switch **01** to the  position to turn on the front parking, side marker, tail, license plate and instrument panel lights.
- Turn the switch **01** to the  position to turn on the headlights.

For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.




first drive features

WINDSHIELD WIPER SWITCH

Move the lever to the following positions to operate the front windshield wipers:

- 01** Mist (**MIST**) - One sweep operation of the front wipers.
- 02** Auto (**AUTO**) (Hardtop models—if so equipped) Operates the rain-sensing auto wiper system.
- 03** Low (**LO**) - Front wipers operate at a continuous low-speed.
- 04** High (**HI**) - Front wipers operate at a continuous high-speed.



For more information, refer to the “**Instruments and controls (section 2)**” of your Owner’s Manual.



AUTOMATIC CLIMATE CONTROLS

01 AUTO BUTTON/TEMPERATURE CONTROL KNOB

- Press the **AUTO** button to turn the system on and the fan speed, air flow distribution and temperature will be automatically maintained. Turn the driver’s side temperature control knob left for cooler air or right for warmer air.

02 ON-OFF BUTTON/FAN SPEED CONTROL KNOB

- Press the button to turn the system off.
- Turn the knob to the left to decrease fan speed or to the right to increase fan speed.

03 DEFROSTING/DEFOGGING FRONT AND SIDE WINDOWS

- Press the front defroster button  to turn the system on or off.

04 REAR WINDOW AND OUTSIDE MIRROR (if so equipped) DEFROSTER SWITCH

- Push the rear window defroster switch  **REAR** to turn the system on or off.

For more information, refer to the “**Instruments and controls (section 2)**” and the “**Monitor, heater, air conditioner, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.



FM/AM/XM®* RADIO WITH CD/DVD PLAYER (if so equipped)

01 VOLUME ON-OFF CONTROL KNOB

- Press the **VOLUME ON-OFF** knob to turn the system on or off.
- Turn the **VOLUME ON-OFF** knob right or left to increase or decrease the volume.

02 TUNE/FOLDER/AUDIO CONTROL KNOB

- To manually tune the radio, turn the **TUNE/FOLDER/AUDIO** knob left or right.

*XM® Satellite Radio is only available on vehicles equipped with optional XM® Satellite subscription service.

For more information, refer to the “**Monitor, heater, air conditioner, audio, phone and voice recognition systems (section 4)**” of your Owner’s Manual.

PARKING BRAKE

- To apply, firmly depress the parking brake pedal **01** .
- To release, firmly press the foot brake **02** , then press the parking brake pedal **01** and the parking brake will release.

For more information, refer to the “**Starting and driving (section 5)**” of your Owner’s Manual.



first drive features

SOFT TOP OPERATION (CrossCabriolet models)

The soft top can be operated only when the trunk is separated by the luggage cover. The luggage cover must be pulled out and hung on both hooks or the top will not operate. Before opening or closing your soft top, refer to the Owner's Manual for detailed warnings and cautions regarding soft top operation.

Soft Top Operation

1. Make sure the area around the vehicle is clear of obstructions and that there is more than 10 feet of clearance from the ground and more than 4.9 feet of clearance from the rear of the vehicle.
2. Pull out the luggage cover and hang on both hooks **01**.
3. Apply the parking brake and move the shift lever to the P (PARK) position.
4. Depress the brake pedal.
5. Start the engine.
6. Push and hold the soft top operating switch, located on the center console, to **OPEN** **02** or **CLOSE** **03** until the top is fully opened or closed.




For more information, refer to the “**Instruments and Controls (section 2)**” and “**Pre-driving checks and adjustments (section 3)**” of your Owner's Manual.

TRUNK LID RELEASE (CrossCabriolet models)

Use one of the following methods to unlatch the trunk lid, then pull the lid up to open the trunk:

- Press the  **HOLD** button on the NISSAN Intelligent Key™ for more than 1 second.
- Push the trunk open request switch while carrying the Intelligent Key with you.
- From inside the vehicle, push the trunk lid release switch.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner's Manual.



POWER LIFTGATE RELEASE (Hardtop models—if so equipped)

Use one of the following methods to unlatch the liftgate, then pull the liftgate up to open:

- Press the  button on the NISSAN Intelligent Key™ for more than 1 second.
- Push the liftgate opener switch while carrying the Intelligent Key with you.
- From inside the vehicle, push the power liftgate switch.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



FUEL-FILLER DOOR

- To open the fuel-filler door, push the opener switch.
- The fuel-filler door is located on the left, rear side of the vehicle.

For more information, refer to the “**Pre-driving checks and adjustments (section 3)**” of your Owner’s Manual.



system guide

CRUISE CONTROL

- The cruise control system enables you to set a constant cruising speed.
- The system will maintain the set speed until you tap the brake pedal, accelerate, cancel or turn the system off.

For more information, refer to the **“Starting and driving (section 5)”** of your Owner’s Manual.



BLUETOOTH® HANDS-FREE PHONE SYSTEM (if so equipped)

- With an overhead microphone and sound transmitted through the audio system speakers, the Bluetooth® Hands-free Phone System utilizes Bluetooth wireless technology and voice recognition to provide hands-free cellular phone communication.

For more information, refer to the **“Monitor, heater, air conditioner, audio, phone and voice recognition systems (section 4)”** of your Owner’s Manual or please visit www.nissanusa.com/bluetooth.



NAVIGATION SYSTEM (if so equipped)

- Your Navigation System can calculate a route from the current location to a preferred destination. The real-time map display and turn-by-turn voice guidance will lead you along the route.
- The Navigation System will continually update your vehicle’s position. If you have deviated from the original route, it will recalculate the route from your current location.
- The Navigation System can also provide you with important data such as distance to empty and maintenance interval reminders.

For more information, refer to the Navigation System Owner’s Manual.

DVD ENTERTAINMENT SYSTEM (if so equipped)

- With this entertainment system, you can play video files via a DVD or CD, providing images and sound from the control panel.
- You can also connect auxiliary devices such as video games, camcorders or portable video players through the auxiliary jacks.
- To view movies on the control panel display, stop the vehicle in a safe location, move the shift lever to the P (PARK) position and apply the parking brake.
- To reduce driver distraction, movies will not be shown on the control panel display while the vehicle is in any drive position.

For more information, refer to the **“Monitor, heater, air conditioner, audio, phone and voice recognition systems (section 4)”** of your Owner’s Manual.



HOMELINK® UNIVERSAL TRANSCEIVER (if so equipped)

- The HomeLink® system can learn and consolidate the functions of up to three different hand-held transmitters, operating items such as garage doors, property gates, outdoor and indoor lights or alarm systems.

For more information, refer to the **“Instruments and controls (section 2)”** of your Owner’s Manual, the HomeLink® website at www.homelink.com or call 1-800-355-3515.



Nissan, the Nissan Brand Symbol, "SHIFT_" tagline,
Z and Nissan model names are Nissan trademarks.
© 2010 Nissan North America, Inc.
QR1E 0Z51U1
Printing: January 2011 (09)

