

Citroen C-ELYSEE (from 2013) – fuse box diagram

Year of production: 2013, 2014, 2015, 2016

Fuse box under dashboard

Fuse	Ampere rating [A]	Functions
F02	5	Headlamp adjusters, diagnostic socket, air conditioning panel
F09	5	Alarm, alarm (accessory)
F11	5	Additional heating
F13	5	Parking sensor, parking sensor (accessory)
F14	10	Air conditioning panel
F16	15	Cigarette lighter, 12V socket
F17	15	Audio system, audio system (accessory)
F18	20	Audio system / Bluetooth, audio system (accessory)
F19	5	Monochrome screen C
F23	5	Courtesy lamps, map reading lamps
F26	5	Horn
F27	15	Screenwash pump
F28	5	Anti-theft
F29	25	Heated door mirrors
F31	—	Not used
F32	—	Not used
F33	30	Front electric windows
F34	30	Rear electric windows
F35	30	Heated front seats
F36	—	Not used
F37	20	Trailer interface

Fuse box in engine compartment

Fuse	Ampere rating [A]	Function
F14	15	Heated lower windscreen
F15	5	Air conditioning compressor
F16	15	Front foglamps
F18	10	Right hand main beam headlamp
F19	10	Left hand main beam headlamp
F29	40	Front wiper motor
F30	80	Pre-heater plugs (Diesel)

WARNING: Terminal and harness assignments for individual connectors will vary depending on vehicle equipment level, model, and market.