


Chevrolet Malibu 2018 fuse box diagram

Engine Compartment Fuse Block

The engine compartment fuse block is on the driver side of the engine compartment, near the battery.



Chevrolet Malibu – fuse box diagram – engine

compartment

Fuses	Usage
1	—
2	—
3	Antilock brake system pump
4	AC DC inverter
6	Trunk
7	Anti-theft warning siren/Horn
8	Window/Mirror/Seats
9	Electric brake boost
10	AOS/Airbag–HEV
11	DC DC battery 1
12	Rear defogger
13	Heated mirror
14	—
15	Passive entry/Passive start
16	Front wiper
17	Passenger power seat

18	Antilock brake system valve
19	Driver power seat
21	Sunroof
22	Parking lamp
23	Active headlamp leveling
24	—
26	Transmission control module/Ignition
27	Instrument panel body/Ignition
28	—
29	Regulated voltage control/Ventilation
30	Malfunction indicator lamp/SS
32	CVS
33	Front heated seat
34	BSM/ESS fan
35	Body control module 6/Body control module 7
37	Fuel module
38	—
39	—
40	Steering column lock
41	—
43	Heated steering wheel
44	Active headlamp leveling
45	—
46	Engine control module/Ignition
47	—
48	Electric brake boost-HEV
49	DC DC battery 2

50	—
51	—
52	—
53	—
54	—
55	—
56	Starter motor
57	Transmission auxiliary pump
58	—
59	High-beam headlamps
60	Cooling fan
61	—
62	—
63	—
65	Air conditioning—HEV
67	—
68	—
69	Right low-beam HID headlamp
70	Left low-beam HID headlamp
72	Starter pinion
74	—
75	Engine control module
76	Powertrain off engine
78	Horn
79	Washer pump
81	Transmission control module/Engine control module
82	—


83	Ignition coil
84	Powertrain on engine
85	Engine control module switch 2
86	Engine control module switch 1
87	SAIR pump
88	Aeroshutter
89	Headlamp washer
91	—
92	Traction power inverter module/Motor generator unit pump
93	Active headlamp leveling
95	SAIR solenoid
96	Fuel heater
97	—
99	Coolant pump

Relays	Usage
4	AC DC inverter
20	Rear defogger
25	Front wiper control
31	Run/Crank
37	Front wiper speed
42	Transmission auxiliary pump
64	Starter motor
68	Powertrain
71	Low-beam HID headlamps
73	Air conditioning
80	Starter pinion/Starter motor

90	SAI reaction solenoid
94	Headlamp washer
98	SAI reaction pump

Instrument Panel Fuse Block

The instrument panel fuse block is in the instrument panel, on the driver side of the vehicle.



Chevrolet Malibu – fuse box diagram – instrument

panel

Fuses	Ampere rating [A]	Usage
F1	30	Left power windows
F2	30	Right power windows
F3	—	—
F4	40	Heating, ventilation, and air conditioning blower
F5	15	Body control module 2
F6	—	Left rear heated seat
F7	—	Right rear heated seat
F8	15	Body control module 3
F9	5	Engine control module/Rear battery
F10	15	Body control module 2 (w/ Stop/Start option)
F11	—	—
F12	—	—
F13	—	—
F14	—	—

F15	20	Transmission control module (w/ Stop/Start option)
F16	30	Amplifier
F17	—	Seat power lumbar
F18	—	OnStar
F19	—	—
F20	15	Body control module 1
F21	15	Body control module 4
F22	—	—
F23	10	Electric steering column lock – China and Russia only
F24	10	Airbag
F25	7,5	Data link connector
F26	—	—
F27	30	AC DC inverter
F28	—	—
F29	20	Body control module 8
F30	10	Overhead console
F31	2	Steering wheel controls
F32	—	—
F33	10	Heating, ventilation, and air conditioning
F34	—	Gateway
F35	—	—
F36	5	Wireless charger
F37	20	Front accessory power outlets/ Cigar lighter (China only)
F38	5	OnStar
F39	7,5	Display
F40	10	Obstacle detection
F41	15	Body control module 1 (w/ Stop/Start option)

F42	15	Radio
CB1	—	—
CB2	15	Console accessory power outlet

Relays	Usage
K1	—
K2	Retained accessory power relay
K3	—
K4	—
K5	—