

Dodge Challenger 2015 fuse box diagram

Front Power Distribution Center

Cavity	Cartridge fuse	Mini Fuse	Description
1	—	—	Fuse – Spare
2	40	—	Radiator Fan #1 – If Equipped
3	50	—	Power Steering #1 / Radiator Fan (6.2L Supercharged) – If Equipped
4	30	—	Starter
5	40	—	Anti-Lock Brakes
6	30	—	Anti-Lock Brakes
7	—	—	Fuse – Spare
8	—	—	Fuse – Spare
9	—	20	All-Wheel Drive Module – If Equipped
10	—	10	Security – If Equipped / Under hood Lamp – Police
11	—	20	Horns
12	—	10	Air Conditioning Clutch

13	—	—	Fuse – Spare
14	—	—	Fuse – Spare
15	—	20	LH HID
16	—	20	RH HID
18	40	—	Radiator Fan #2 – If Equipped
19	50	—	Power Steering #2 / Radiator Fan (6.2L Supercharged)
20	30	—	Wiper Motor
21	30	—	Headlamp Washers – If Equipped
22	40	—	Engine Cooling/Intercooler Pump / Police Bat Feed # 3 – If Equipped
	20		
23	20	—	Police Bat Feed # 1 – If Equipped
24	20	—	Police Bat Feed # 3 – If Equipped
28	—	—	Fuse – Spare
29	—	15	Transmission – If Equipped
30	—	—	Fuse – Spare

31	—	25	Engine Module
32	—	—	Fuse – Spare
33	—	—	Fuse – Spare
34	—	25	Powertrain #1
35	—	20	Powertrain #2
36	—	10	Anti-Lock Brake Module
37	—	10	Engine Controller/Rad Fan Relays – If Equipped
38	—	10	Airbag Module
39	—	10	Power Steering Module/AC Clutch Relay
48	—	10	AWD Module/Front Axle Disconnect/Adaptive Cruise – if Equipped
49	—	—	Fuse – Spare
50	—	—	Fuse – Spare
51	—	20	Vacuum Pump
52	—	10	Driver Assistance Systems Module – If Equipped
53	—	—	Fuse – Spare

Rear power distribution center

Cavity	Cartridge fuse	Mini fuse	Description
2	60	—	Front PDC Feed #1
3	—	—	Fuse – Spare
4	60	—	Front PDC Feed #2
5	30		Sunroof / Dome Lamp – Police
	20		
6	40	—	Exterior Lighting #1
7	40	—	Exterior Lighting #2
8	30	—	Interior Lighting/Washer Pump – If Equipped
9	40	—	Power Locks
10	30	—	Driver Door
11	30	—	Passenger Door
12	—	20	Cigar Lighters, Instrument Panel & Power Outlet Console Rear
15	40	—	HVAC Blower
16	20	—	Left Spot Lamp – Police

17	—	—	Fuse – Spare
18	20	—	Active Dampening Module – If Equipped
19	—	—	Fuse – Spare
20	—	—	Fuse – Spare
21	30	—	Fuel Pump (LD 6.2L Supercharged)
22	—	20	Right Spot Lamp – Police
23	—	10	Fuel Door/Diagnostic Port
24	—	15	Radio Screen
25	—	10	Tire Pressure Monitor
26	—	15	Transmission (LD/LX)
	—	25	Fuel Pump (LA)
	—	30	Fuel Pump (LA 6.2L Supercharged)
27	—	25	Amplifier / Spare – If Equipped
31	—	25	Power Seats
32	—	15	HVAC Module/Cluster

33	—	15	Ignition Switch/Wireless Module
34	—	10	Steering Column Module/Clock/Spare – Police
35	—	5	Battery Sensor
36	—	15	Electronic Exhaust Valve – If Equipped
37	—	15	Radio
38	—	20	Power Outlet Inside Arm Rest
40	—	—	Fuse – Spare
41	—	—	Fuse – Spare
42	30	—	Rear Defrost
43	—	20	Rear Heated Seats/Steering Wheel
44	—	10	Park Assist/Blind Spot/Camera
45	—	15	Cluster/Rearview Mirror/Compass
46	—	10	Adaptive Cruise Control – If Equipped
47	—	10	Adaptive Front Lighting – If Equipped
48	—	20	Active Suspension / Spare – Police

49	—	—	Fuse — Spare
50	—	—	Fuse — Spare
51	—	20	Front Heated Seats – If Equipped
52	—	10	Heated Cupholders/Rear Heated Seat Switches – If Equipped
53	—	10	HVAC Module/In Car Temperature Sensor
54	—	10	Airbag Module
55	—	—	Fuse — Spare
56	—	—	Fuse — Spare
57	—	—	Fuse — Spare
58	—	10	Airbag Module
59	—	20	Adjustable Pedals – Police
60	—	—	Fuse — Spare
61	—	20	Cigar Lighter – If Equipped
62	—	—	Fuse — Spare
63	—	—	Fuse — Spare

64	—	25	Rear Windows
65	—	10	Airbag Module
66	—	—	Fuse — Spare
67	—	15	Run Sense
68	—	15	Illumination/Rear Sunshade/CTR Console Power Outlet – If Equipped
	—	10	
69	—	—	Fuse — Spare
70	—	—	Fuse — Spare