


Chevrolet Corvette 1995 – 1996 fuse box diagram

Instrument panel fuse block

The interior fuse center is on the right side of your instrument panel. Turn the knob and pull the door to access the fuses.



Chevrolet Corvette – fuse box – instrument panel


Fuses	Usage
1	Heater, A/C Programmer
2	Brake-Transmission Shift Interlock
3	Windshield WiperNasher Switch Assembly
4	Radio Receiver (Ignition)
5	Heated Mirrors, Heater and A/C Control Head, Heater and A/C Programmer
6	Light Switch, Daytime Running Lamps Module
7	Horn Relay
8	Hazard Flashers, Brake Switch
9	Crank-Air Bag
10	Crank-Park/Neutral Switch (Automatic), Clutch Switch (Manual)
11	RH Illumination
12	LH Illumination
13	Console Illumination
14	Fuel Pump 1
15	Automatic Transmission
16	Central Control Module, Daytime Running Lamps Module
17	Generator
18	A/C .Compressor Clutch, Heater and A/C Control Head, Heater and A/C Programmer, Rev Defog Relay
19	Accessory Plug
20	Heated Oxygen Sensors
21	Real Time Damping Module, ABS Module, HVAC Solenoid Assembly

22	Injectors #1,4,6,7
23	Injectors #2,3,5, 8
24	Turn Signal Flashers
25	Ignition Coil and Ignition Coil Module
26	Passive Keyless Entry Module
27	Instrument Cluster, Driver Information Center, Air Bag System
28	Back-up Lamps Switch, Transmission Position Switch, One to Four Shift Solenoid
29	Cooling Fan Relay Coil #1 , 2,3
30	Canister Purge Solenoid, EGR Circuit (LTI), Mass Airflow Sensor, One to Four Shift Relay, Brake Switch (Automatic), Air Pump Relay
31	Power Mirror Adjuster Control, Lighted Rearview Mirror, Visor Vanity Mirrors
32	Cruise Control Engage Switch, Daytime Running Lamps Module, Low Tire Pressure Warning Module, Cruise Control Cut-off Relay
33	Engine Control Module
34	Air Bag System
35	Central Control Module
36	Footwell Courtesy Lamps, Door Courtesy Lamps, Glove Compartment Lamps, Lighted Rearview Mirror
37	Bose Amplifier Relay, Power Antenna Relay, Cargo Compartment Lamps
38	Instrument Cluster, Tone Generator, Dome Lamp Relay
39	Central Control Module
40	Radio Receiver (Battery), Radio Control Head, Passive Keyless Entry Module
41	Sport Seats
42	Power Door Lock Switches, Driver Information Center, Passive Keyless Entry Module
43	Heater and A/C Programme
44	Cigarette Lighter, Accessory Plug
45	Hatch or Deck Lid Release Relay
K	Power Seats
L	Blank
M	Power Window
N	Blank
P	Blank

Engine compartment fuse block

There are two maxi-fuse blocks in the engine compartment. One is part of the forward lamp wiring harness and the other is part of the ECM-engine wiring harness.

Forward Lamp Fuse Block



Chevrolet Corvette – fuse box – forward lamp fuse block

Fuse	Usage
1	Interior Lighting
2	Primary Cooling Fan
3	LH Headlamp Motor
4	RH Headlamp Motor
5	Secondary Cooling Fan
6	Exterior Lighting
7	Power Accessory (Power Locks, Hatch, Lighter, Seats)
8	Air Pump

ECM Engine Fuse Block



Chevrolet Corvette – fuse box – ECM engine fuse block

Fuse	Usage
1	Engine Control Module

2	Fuel Pump
3	Anti-Lock Brakes, Acceleration Slip Regulation System
4	A/C Blower
5	Rear Defogger
6	Ignition
7	Ignition
8	Brake Hydraulics