



Chevrolet Orlando J309 2011 – 2018 fuse box diagram

Engine compartment fuse box



Chevrolet Orlando J309 – fuse box diagram –




engine compartment fuse box diagram – engine compartment

No.	A	Description
1	15	Transmission Control Module
2	15	Engine Control Module
3	N/A	Not Used
5	15	Transmission Control Module, Engine Control Module, Mass Air Flow/Intake Air Temperature Sensor, Output Speed Sensor
6	30	Windshield Wiper Relays
7	N/A	Not Used
8	15	Fuel injectors
9	15	Ignition Coil, Fuel Injectors
10	15	Engine Control Module, Output Speed Sensor
11	10	Heated Oxygen Sensors
12	30	Starter Motor
13	7.5	Evaporative Emission (EVAP) Canister Vent Solenoid Valve
14	N/A	Not Used
15		Rear Wiper
16	7.5	Air Quality Sensor
17	5	Inflatable Restraint Sensing and Diagnostic Module
18	10	Fuel Pump Control Module
19	N/A	Not Used

20	20	Fuel Pump Relay
21	30	Windows Motors, Front Door
22	N/A	Not Used
23	N/A	Not Used
24	30	Windows Motors, Front Door
25		Electronic Vacuum Pump
26	40	Electronic Brake Control Module (EBCM)
27	30	Remote Control Door Lock Receiver
28	40	Rear Demister Grid
29	N/A	Not Used
30	15	Electronic Brake Control Module (EBCM)
31	20	Body Control Module
32	20	Body Control Module
33	30	Heated Seat Control Module
34	25	Sunroof Control Module
35	30	Audio Amplifier
36	N/A	Not Used
37	10	Headlamp – Right Main beam
38	10	Headlamp – Left Main beam
39	N/A	Not Used
40	N/A	Not Used
41	N/A	Not Used
42	20/30	Cooling Fan Relays, Cooling Fan Motor
43	N/A	Not Used
44	N/A	Not Used
45	30/40	Cooling Fan High Speed Relay, Cooling Fan Motor
46	10	Cooling Fan Relays
47	10	Heated Oxygen Sensors, Throttle Body
48	15	Fog Lights, Front
49	N/A	Not Used
50	N/A	Not Used
51	15	Horn
52	5	Instrument Cluster
53	10	Inside Rearview Mirror
54	5	Headlamp Switch, Electrical Auxiliary Heater, HVAC Control Module
55	7.5	Window Switches, Front, Mirror Switch
56	15	Windscreen Washer Pump
57	15	Steering Column Lock Control Module
58	N/A	Not Used

59	30	Fuel Heater
60	7.5	Outside Rearview Mirrors
61		Mirror Defogger
62	10	A/C Compressor Clutch Relay, A/C Compressor Clutch
63		Rear Window Sensor
64	5	Inflatable Restraint Sensing and Diagnostic Module
65		Rear Fog Lamp
66		Rear Washer
67	20	Fuel Pump Control Module
68	N/A	Not Used
69	5	Body Control Module
70	5	Rain Sensor
71	N/A	Not Used
Relays		
1	A/C Compressor Clutch	
2	Starter	
3	Cooling Fan	
4	Windshield Wiper Speed Control	
5	Windshield Wiper	
6	Not Used	
7	Powertrain	
8	Fuel Pump	
9	Cooling Fan Medium Speed 1	
10	Cooling Fan Medium Speed 2	
11	Not Used	
12	Cooling Fan Speed Control (Or in Relay Block – Under-bonnet)	
13	Cooling Fan High Speed Relay	
14	Not Used	
15	Ignition Main Relay	
16	Fuel Heater Relay	
17	Rear Window Defogger	
Note: Relays listed below are non-serviceable Printed Circuit Board (PCB) relays and are internal to the block.		
–	Horn Relay	
–	Windscreen Washer Pump Relay	
–	Front Fog Lamp Relay	
–	Headlamp High Beam Relay	

Instrument Panel Fuse Block




Chevrolet Orlando J309 – fuse box diagram – instrument

panel

No.	A	Description
1	10	Mobile Telephone Control Module
2	–	DC/DC Converter
3	25	Body Control Module
4	20	Radio
5	7.5	Parking Assist Control Module, Power Sounder, Multifunction Switch – Centre Console, Display
6	20	Cigar Lighter
7	20	Power Outlet
8	30	Body Control Module
9	30	Body Control Module
10	30	Body Control Module
11	40	Blower Motor Control Module
12	N/A	Not Used
13	25	Heated Seat Control Module
14	7.5	Data Link Connector, Oil Feeding Connector
15	10	Inflatable Restraint Sensing and Diagnostic Module
16	10	Rear Compartment Lid Release Relay
17	15	HVAC Control Module / HVAC Control Assembly
18		Trailer
19		Battery Sensor
20	–	Not Used
21	15	Instrument Cluster
22	2	Ignition Switch
23	20	Body Control Module
24	20	Body Control Module


25	—	Not Used
26	20	Auxiliary Power Outlet
Note: Relays listed below are non-serviceable Printed Circuit Board (PCB) relays and are internal to the block		
1	Tailgate Release Relay	
2	Logistic Mode Relay 1	
3	Auxiliary Power Relay	

Fuse box above battery




Chevrolet Orlando J309 – fuse box diagram – above battery

No.	A	Description
1	100	Fuse Block – Instrument Panel
2	100	Fuse Block – Instrument Panel
3	80	Electrical Power Steering (EPS) (NJ1)
4	N/A	Not Used
5	250	Fuse Block – Battery Auxiliary
6	250/500	Starter Motor



.Chevrolet Orlando J309 – fuse box diagram – above battery

No.	A	Description
5	80	Glow Plug Control Module
6	100	Electrical Auxiliary Heater
7	N/A	Not Used
8	N/A	Not Used



.Chevrolet Orlando J309 – fuse box diagram –
above battery

No.	Relays
1	Cooling Fan Left Medium Speed Relay
2	Cooling Fan Speed Control 2 Relay
3	Cooling Fan Right Medium Speed Relay