

MA

ENGINE

GENERAL MAINTENANCE

HINT:
Inspect these items on a cooled down engine.

1. INSPECT DRIVE BELT

Type	See procedures
1ZZ-FE	See page EM-1

2. REPLACE ENGINE OIL AND OIL FILTER

Type	See procedures
1ZZ-FE	See page LU-3

3. REPLACE ENGINE COOLANT

Type	See procedures
1ZZ-FE	See page CO-5

4. INSPECT EXHAUST PIPES AND MOUNTINGS

- (a) Visually check the pipes, hangers and connections for severe corrosion, leaks or damage.

5. REPLACE SPARK PLUGS

Type	See procedures
1ZZ-FE	See page IG-3

6. INSPECT BATTERY

Type	See procedures
1ZZ-FE	See page CH-1

7. INSPECT AIR CLEANER FILTER

- (a) Remove the air filter.
- (b) Visually check that the air filter is not excessively damaged or oily. If necessary, replace the air filter.
- (c) Reinstall the air filter.

8. REPLACE AIR CLEANER FILTER

- (a) Replace the air filter with a new one.

9. INSPECT FUEL TANK CAP GASKET

Type	See procedures
1ZZ-FE	See page EC-7

10. INSPECT FUEL LINES AND CONNECTIONS AND FUEL TANK VAPOR VENT SYSTEM HOSES AND FUEL TANK BANDS

- (a) Visually check the fuel lines for cracks, leakage, loose connections, deformation or tank band looseness.

11. INSPECT CHARCOAL CANISTER

Type	See procedures
1ZZ-FE	See page EC-8

