



FUEL TANK COMPONENTS



FU

cardiagn.com

FU



N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

FUEL TANK MAIN TUBE SUB-ASSEMBLY

FUEL TANK VENT HOSE

FUEL TANK ASSEMBLY

FUEL TANK BAND
SUB-ASSEMBLY NO. 1

39 (400, 29)

FUEL TANK INLET PIPE
FUEL HOSE NO. 1

FUEL HOSE PROTECTOR

FUEL TANK BAND SUB-
ASSEMBLY NO. 1 LH

39 (400, 29)

NO. 2 PARKING BRAKE
CABLE ASSEMBLY

5.4 (55, 48 in.*lbf)

NO. 1 FUEL TANK
PROTECTORNO. 3 PARKING BRAKE
CABLE ASSEMBLY

5.4 (55, 48 in.*lbf)

5.4 (55, 48 in.*lbf)

x4

N*m (kgf*cm, ft.*lbf) : Specified torque

Y

A119657E03

FU

cardiagn.com