



MANUAL TRANSAXLE ASSEMBLY


COMPONENTS




N*m (kgf*cm, ft.*lbf) : Specified torque



FRONT DRIVE SHAFT ASSEMBLY RH



FRONT DRIVE SHAFT ASSEMBLY LH



* For use with SST

Y

C119544E04