

CRUISE CONTROL SYSTEM

PRECAUTION

1. **Pay attention to the following points when inspecting the cruise control system.**
 - (a) Push the cruise control main switch ON-OFF button off when not using the cruise control.
 - (b) Be careful of vehicle speed increase when driving downhill with the cruise control on.
 - (c) RES/ACC (RESUME/ACCELERATION) operation, after canceling the cruise control, works as RESUME, and works as ACCELERATION while the cruise control system is in operation.
 - (d) Push the cruise control main switch ON-OFF button off and reset the cruise control if the CRUISE main indicator light blinks while the cruise control system is in operation. When the cruise control cannot be set by this procedure or cancelled immediately after setting, there may be a malfunction in the system.
 - (e) Do not use the cruise control system where the road conditions are as follows:
 - Heavy traffic
 - Steep downhill
 - Sharp turns
 - Icy or snowy roads
 - Slippery roads

CC

HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester can be used at steps 4, 5, 6, and 10.

1

VEHICLE BROUGHT TO WORK SHOP

NEXT

2

CUSTOMER PROBLEM ANALYSIS

NEXT

3

PROBLEM SYMPTOM CONFIRMATION

NEXT

4

DTC CHECK AND CLEAR

NEXT

5

DTC CHECK

➤

TROUBLE CODE (GO TO STEP 6)

➤

NORMAL SYSTEM CODE (GO TO STEP 7)

6

DTC CHART

NEXT

GO TO STEP 10

7

PROBLEM SYMPTOM SIMULATION

➤

SYMPTOM DOES NOT OCCUR (GO TO STEP 8)

➤

SYMPTOM OCCURS (GO TO STEP 9)

CC

8 SYMPTOM SIMULATION

NEXT

9 PROBLEM SYMPTOMS TABLE

NEXT

10 CIRCUIT INSPECTION

NEXT

11 TERMINAL OF ECM

NEXT

12 IDENTIFICATION OF PROBLEM

NEXT

13 REPAIR OR REPLACE

NEXT

14 CONFIRMATION TEST

NEXT

END

CC