

INSTALLATION

1. **INSTALL REAR BUMPER ARM LH**
 - (a) Install the rear bumper arm LH with the 3 bolts.
Torque: 36 N*m (367 kgf*cm, 27 ft.*lbf)
 - (b) Use the same procedures described for the LH side.
2. **INSTALL REAR BUMPER REINFORCEMENT NO. 5**
 - (a) Install the 2 rear bumper reinforcements No. 5 to the rear bumper reinforcement No. 1 with the 4 clips.
3. **INSTALL REAR BUMPER REINFORCEMENT NO. 1**
 - (a) Install the rear bumper reinforcement No. 1 with the 4 nuts.
Torque: 36 N*m (367 kgf*cm, 27 ft.*lbf)
4. **INSTALL BUMPER MOULDING SET BOLT NO. 1**
5. **INSTALL REAR SPOILER (w/ Rear Spoiler)**
 - (a) Install the rear spoiler retainer and rear spoiler with the 3 retainers and 2 screws.
6. **INSTALL REAR BUMPER SPOILER LH (w/ Rear Spoiler)**
 - (a) Install the rear bumper spoiler LH with the 4 retainers.
7. **INSTALL REAR BUMPER SPOILER RH (w/ Rear Spoiler)**
 - (a) Install the rear bumper spoiler RH with the hook and 3 retainers.
8. **INSTALL REAR BUMPER BAR REINFORCEMENT CENTER**
 - (a) Install the rear bumper bar reinforcement to the rear bumper energy absorber.
9. **INSTALL REAR BUMPER ENERGY ABSORBER**
10. **INSTALL REAR BUMPER COVER**
 - (a) Install the rear bumper cover with the 2 hooks and 2 clips.
 - (b) Install the 8 screws and 6 nuts.
Torque: 5.5 N*m (55 kgf*cm, 47 in.*lbf)
11. **INSTALL DECK TRIM COVER REAR**
 - (a) Install the deck trim cover rear with the 2 clips.
12. **INSTALL DECK BOARD SUB-ASSEMBLY**