


Vauxhall Meriva A 2002 – 2010 fuse box diagram

Fusebox in passenger compartment



Vauxhall Meriva A – fuse box –

passenger compartment

Number	Circuit	Ampere rating
1	Central control unit	7,5
2	Immobiliser, hazard warning lights, exterior lighting	5
3	Headlight wash system	30
4	Infotainment system, diesel engine	20
5	—	—
6	—	—
7	Starter, diesel engine: engine controller	10
8	Horn	15
9	Fuel injection system, fuel pump, stationary heater	20
10	Turn signal lights	20


11	Infotainment system, Information display	20
12	Heated rear window, exterior mirrors	7,5
13	Central locking , Vauxhall alarm system	10
14	Engine control: Petrol engine	15
	Engine control: Diesel engine	7,5
15	Engine control unit,	10
	Z 17 DTH engine	15
16	Accessory socket, cigarette lighter	20
17	—	—
18	Adaptive Forward Lighting (AFL)	15
19	Central locking system	20
20	Interior lighting, reading light	5
21	Windscreen wash system	15
22	Rear electric windows	20
23	Slide / tilt sunroof, skylight roof	20

24	Vauxhall alarm system	5
25	Rear window wiper	15
26	Ignition system, engine electronics	15
27	Engine control, airbags, ESP®Plus	5
28	Air conditioning system	7,5
29	Front left electric window	20
30	—	—
31	Engine control	7,5
	Z 17 DTH engine	10
32	Front right electric window	20
33	Central control module, immobiliser, control indicators	5
34	Windscreen wiper	30
35	Interior lighting, interior mirror, information display	5
36	Brake light, ABS, ESP®Plus	15
37	Cigarette lighter, auxiliary heater	20

38	Seat heater (left)	15
39	Seat heater (right)	15
40	Adap tive Forward Lighting (AFL), automatic headlight range adjustment	5
41	Reversing lights	15
42	Engine cooling, lighting	5
43	Left parking light	5
44	Right parking light	5
45	Fog tail light	10
46	Front fog lights	15
47	Towing equipm ent, accessory socket	20
48	Diesel filter heater	30
49	–	–
50	Diesel filter heater	30
51	Left dipped beam: Xenon headlight	15
	Halogen headlight	10

52	Right dipped beam : Xenon headlight	15
	H alogen hea dlight	10
53	Sunroof, electric windows, radio	5
54	Main beam (left)	10
55	Main beam (right)	10
56	—	—

Fusebox in engine compartment



Vauxhall Meriva A – fuse box – engine

compartment

Number	Circuit	Ampere rating [A]
1	Interior fan	30
2	Electric Power Steering (EPS)	50
3	ABS	40

4	Easytronic	60
	diesel preheating system	80
5	Heated rear window	30
6	Engine cooling	50
7	Starter	30
8	Engine cooling	40